

6 INTERACTIVE INPUT, 801-999

6.1 CARDS 801 THROUGH 999, INTERACTIVE INPUT DATA

An interactive control function is available with the Nuclear Plant Analyzer (NPA) version. This function allows a user to interactively control the trip logic, valve area, mass flow rate of the time-dependent junctions, and heater power.

These data may be entered for batch and interactive jobs. However, the interactive control input data have no effects in the case of batch job. In the case of interactive jobs, an interactive control window is provided for the interactive control. The interactive control input data cards can be used in a NEW or RESTART job. In a restart job, these data can be added (cannot be replaced or removed).

These cards define variables that can be interactively changed during execution by user. The card input defines input variable names (variable code and parameter) and comments.

- | | |
|-------|--|
| W1(A) | Type of interactive control (alphanumeric). Enter one of the following interactive control types; "trip" for trip control, "vlvarea" for servo valve area control, "mflowfj" for liquid flow rate control of a time-dependent junction, "mflowgj" for vapor flow rate control of a time-dependent junction, and "power" for heater power control. |
| W2(I) | Parameter (numeric). The parameter is defined according to the type of interactive control as follows: trip card number (400 through 799) for trip control, valve component number (ccc) for servo valve area control, time-dependent junction number (ccc) for liquid flow rate control, time-dependent junction number (ccc) for vapor flow rate control, and general table number (ttt) for heater power control. |
| W3(A) | Comments (alphanumeric). Enter comments for the interactive control. The comment should not be more than 32 characters including quotation marks. These comments are displayed in the interactive control window. |

It is noted that relevant input data should exist for interactive control. That is, for interactive trip control, the trip input should be entered. The value of the trip is determined by user-specified trip input if user action is not given, but upon the user action the value is manually changed. In the same manner, a servo valve component input should be entered for valve area control, and a time-dependent junction component input should be entered for mass flow rate control. For heater power control, the general table input for "power" should be prepared.

