

W4(R) $C_R (\geq 0)$. This quantity must be greater than or equal to 0.

W5(I) Junction number.

8.9.20 CANDU Channel ORNL ANS Interphase Model Values, CCC3101-3199

These cards are required of any of the interphase friction flags b in the volume control flags entered on cards CCC1001-1099 are set to 2.

W1(R) Gap (distance between side walls, short length, pitch, channel width) (m, ft).

W2(R) Span (distance from one end to the other, long length) (m, ft).

W3(I) Volume number.

8.10 Branch Component, BRANCH

A branch component is indicated by BRANCH for Word 2 on card CCC0000. The connection code is CCCVV000N, where CCC is the component number, VV is the volume number, and N is the face number. More than one junction may be connected to the inlet or outlet. If an end has no junctions, that end is considered a closed end. If more than one junction is connected on one end of a branch, each junction should be modeled as an abrupt area change. For major edits, minor edits, and plot variables, the volume in the branch component is numbered as CCC010000. The junctions associated with the branch component are numbered as CCCJJ0000, where JJ is the junction number ($01 \leq JJ \leq 09$).

8.10.1 Branch Component Information, CCC0001

This card is required.

W1(I) Number of junctions, n_j . The variable n_j is the number of junctions described in the input data for this component ($0 \leq n_j \leq 9$). Not all junctions connecting to the branch need be described with this component input, and n_j is not necessarily the total number of junctions connecting to the branch. Junctions described in single-junctions, time-dependent junctions, pumps, circulators, separators, jetmixers, ECC mixers, and other branches can be connected to this branch.

W2(I) Initial condition control. This word is optional and, if missing, the junction initial velocities in the first and second words on card CCCN201 are assumed to be velocities. If 0, velocities are assumed; if nonzero, mass flows are assumed.

8.10.2 Branch X-Coordinate Volume Data, CCC0101-0109

This card (or cards) is required. The nine words can be entered on one or more cards, and the card numbers need not be consecutive.

- W1(R) Area (m², ft²).
- W2(R) Length (m, ft).
- W3(R) Volume (m³, ft³). The code requires that the volume equals the area times the length ($W3 = W1 \bullet W2$). At least two of the three quantities, W1, W2, and W3, must be nonzero. If one of the quantities is 0, it will be computed from the other two. If none of the words are 0, the volume must equal the x-direction area times the x-direction length within a relative error of 0.000001. The same relative error check is done for the y- and z-directions.
- W4(R) Azimuthal angle (degrees). The absolute value of this angle must be ≤ 360 degrees. This quantity is not used in the calculation but is specified for possible automated drawing of nodalization diagrams.
- W5(R) Inclination angle (degrees). The absolute value of this angle must be ≤ 90 degrees. The angle 0 degrees is horizontal, and positive angles have an upward inclination, i.e., the inlet is at the lowest elevation. This angle is used in the interphase drag calculation.
- W6(R) Elevation change (m, ft). A positive value is an increase in elevation. The absolute value of this quantity must be less than or equal to the length. If the vertical angle orientation is 0, this quantity must be 0. If the vertical angle is nonzero, this quantity must also be nonzero and have the same sign. When the absolute value of the elevation angle determined by the ratio of the elevation change (this Word 6) and the length (Word 2) is less than or equal to 45 degrees, the horizontal flow regime map is used. When the ratio is greater than 45 degrees, the vertical flow regime map is used.
- W7(R) Wall roughness (m, ft).
- W8(R) Hydraulic diameter (m, ft). This should be computed from $4.0 \bullet \left(\frac{\text{area}}{\text{wetted perimeter}} \right)$.
If 0, the hydraulic diameter is computed from $2.0 \bullet \left(\frac{\text{area}}{\pi} \right)^{0.5}$. A check is made that the pressurizer roughness is less than half the hydraulic diameter. See Word 1 for the area.
- W9(I) Volume control flags. This word has the format tlpybfe. It is not necessary to input leading zeros. Volume flags consist of scalar oriented and coordinate direction oriented flags. Only one value for a scalar oriented flag is entered per volume but up to three coordinate

oriented flags can be entered for a volume, one for each coordinate direction. At present, the f flag is the only coordinate direction oriented flag. This word enters the scalar oriented flags and the x-coordinate flag.

t-flag	The digit $\underline{t}$ specifies whether the thermal front tracking model is to be used; $\underline{t} = 0$ specifies that the front tracking model is not to be used for the volume, and $\underline{t} = 1$ specifies that the front tracking model is to be used for the volume.
l-flag	The digit $\underline{l}$ specifies whether the mixture level tracking model is to be used; $\underline{l} = 0$ specifies that the level model not be used for the volume, and $\underline{l} = 1$ specifies that the level model be used for the volume.
p-flag	The digit $\underline{p}$ specifies whether the water packing scheme is to be used. $\underline{p} = 0$ specifies that the water packing scheme is to be used for the volume, and $\underline{p} = 1$ specifies that the water packing scheme is not to be used for the volume.
v-flag	The digit $\underline{v}$ specifies whether the vertical stratification model is to be used. $\underline{v} = 0$ specifies that the vertical stratification model is to be used for the volume, and $\underline{v} = 1$ specifies that the vertical stratification model is not to be used for the volume.
b-flag	The digit $\underline{b}$ specifies the interphase friction that is used. $\underline{b} = 0$ means that the pressurizer interphase friction model will be applied, $\underline{b} = 1$ means that the rod bundle interphase friction model will be applied, $\underline{b} = 2$ means that the ORNL ANS interphase friction model will be applied (see card ccc0111 in Section 8.10.3).
f-flag	The digit $\underline{f}$ specifies whether wall friction is to be computed. $\underline{f} = 0$ specifies that wall friction effects are to be computed along the x-coordinate direction in the volume, and $\underline{f} = 1$ specifies that wall friction effects are not to be computed along the x-coordinate.
e-flag	The digit $\underline{e}$ specifies if nonequilibrium or equilibrium is to be used. $\underline{e} = 0$ specifies that a nonequilibrium (unequal temperature) calculation is to be used, and $\underline{e} = 1$ specifies that an equilibrium (equal temperature) calculation is to be used. Equilibrium volumes should not be connected to nonequilibrium volumes. The equilibrium option is provided only for comparison to other codes.

8.10.3 Branch ORNL ANS Interphase Model Values, CCC0111

This card is required if the interphase friction flag $\underline{b}$ in Word 9 of card CCC0101-0109 is set to 2.

W1(R)	Gap (distance between side walls, short length, pitch, channel width) (m, ft).
W2(R)	Span (distance from one end to the other, long length) (m, ft).

W3(I) Volume number.

8.10.4 Branch Additional Wall Friction, CCC0131

This card is optional. If this card is not entered, the default values are 1.0 for the laminar shape factor and 0.0 for the viscosity ratio exponent. Two, four, or six quantities may be entered on the card, and the data not entered are set to default values.

W1(R) Shape factor for x-coordinate.

W2(R) Viscosity ratio exponent for x-coordinate.

W3(R) Shape factor for y-coordinate.

W4(R) Viscosity ratio exponent for y-coordinate.

W5(R) Shape factor for z-coordinate.

W6(R) Viscosity ratio exponent for z-coordinate.

8.10.5 Branch Y-Coordinate Volume Data, CCC0181-0189

These cards are optional. These cards are used when the user specifies the y-direction connection with the crossflow model. The volume of the volume is the same for the x-, y-, and z-directions. If these cards are entered, either W1 or W2 must be nonzero.

W1(R) Area (m^2 , ft^2). If these cards are missing or if this word is 0, this y-direction area is computed from $\frac{\text{volume}}{\text{y-direction length}}$.

W2(R) Length (m, ft). If these cards are missing, this y-direction length is computed from $2.0 \cdot \left(\frac{\text{x-direction area}}{\pi} \right)^{0.5}$. If this word is 0, this y-direction length is computed from $\frac{\text{volume}}{\text{y-direction area}}$.

W3(R) Roughness (m, ft).

W4(R) Hydraulic diameter (m, ft). If these cards are missing or if this word is 0, this y-direction hydraulic diameter is computed from $4.0 \cdot \left(\frac{\text{y-direction area}}{\pi \cdot \text{x-direction area}} \right)^{0.5}$. A check is

made to ensure the y-direction roughness is less than half the y-direction hydraulic diameter.

W5(I) Volume control flags. This word has the general format tlpybfe, but this word is limited to 00000f0 since it only enters the coordinate oriented flags for the y-direction.

f-flag The digit f specifies whether wall friction is to be computed. f = 0 specifies that wall friction effects are to be computed along the y-coordinate direction in the volume, and f = 1 specifies that wall friction effects are not to be computed along the y-coordinate direction.

W6(R) This word is not used. Enter 0.

W7(R) This word is not used. Enter 0.

W8(R) This word is the position change in the z-fixed (vertical) direction as the flow passes from the y-inlet face to the y-outlet face (m, ft). This quantity affects problems if connections are made to the y-faces.

8.10.6 Branch Z-Coordinate Volume Data, CCC0191-0199

These cards are optional. These cards are used when the user specifies the z-direction connection with the crossflow model. The volume of the volume is the same for the x-, y-, and z-directions. If these cards are entered, either W1 or W2 must be nonzero.

W1(R) Area (m², ft²). If these cards are missing or if this word is 0, this z-direction area is computed from $\frac{\text{volume}}{\text{z-direction length}}$.

W2(R) Length (m, ft). If these cards are missing, this z-direction length is computed from $2.0 \cdot \left(\frac{\text{x-direction area}}{\pi} \right)^{0.5}$. If this word is 0, this z-direction length is computed from $\frac{\text{volume}}{\text{z-direction area}}$.

W3(R) Roughness (m, ft).

W4(R) Hydraulic diameter (m, ft). If these cards are missing or if this word is 0, this z-direction hydraulic diameter is computed from $4.0 \cdot \left(\frac{\text{z-direction area}}{\pi \cdot \text{x-direction area}} \right)^{0.5}$. A check is made to ensure the z-direction roughness is less than half the z-direction hydraulic diameter.

- W5(I) Volume control flags. This word has the general format tlpybfe, but this word is limited to 00000f0 since it only enters the coordinate oriented flags for the z-direction.
- f-flag The digit f specifies whether wall friction is to be computed. f = 0 specifies that wall friction effects are to be computed along the z-coordinate direction in the volume, and f = 1 specifies that wall friction effects are not to be computed along the z-coordinate direction.
- W6(R) This word is not used. Enter 0.
- W7(R) This word is not used. Enter 0.
- W8(R) This word is the position change in the z-fixed (vertical) direction as the flow passes from the z-inlet face to the z-outlet face (m, ft). This quantity affects problems if connections are made to the z-faces.

8.10.7 Branch Volume Initial Conditions, CCC0200

This card is required.

- W1(I) Control word. This word has the format εbt. It is not necessary to input leading zeros.
- ε-flag The digit ε specifies the fluid, where ε = 0 is the default fluid. The value for ε > 0 corresponds to the position number of the fluid type indicated on the 120-129 cards (i.e., ε = 1 specifies H₂O, ε = 2 specifies D₂O etc.). The default fluid is that set for the hydrodynamic system by cards 120-129 or this control word in another volume in this hydrodynamic system. The fluid type set on cards 120-129 or these control words must be consistent (i.e., not specify different fluids). If cards 120-129 are not entered and all control words use the default ε = 0, then water is assumed to be the fluid. It is recommended that the user use the 120-129 cards to set the fluid type in the systems.
- b-flag The digit b specifies whether boron is present. b = 0 specifies that the volume liquid does not contain boron, and b = 1 specifies that a boron concentration in mass of boron per mass of liquid (which may be 0) is being entered after the other required thermodynamic information.
- t-flag The digit t specifies how the following words are to be used to determine the initial thermodynamic state. t = 0-3 specifies one component (steam/water); t = 4-6 allows the specification of two components (steam/water and noncondensable gas).
- With options t equal to 4-6, names of the components of the noncondensable gas must be entered on card 110, and mass fractions of the noncondensable gas components are entered on card 115.

One Component (Steam/Water), Equilibrium or Non-equilibrium

[P,U_f,U_g,α_g] If $\underline{t} = 0$, the next four words are interpreted as pressure (Pa, lb_f/in²), liquid specific internal energy (J/kg, Btu/lb), vapor specific internal energy (J/kg, Btu/lb), and vapor void fraction. These quantities will be interpreted as nonequilibrium or equilibrium conditions depending on the internal energies used to define the thermodynamic state. Enter boron in W6 if needed.

One Component (Steam/Water), Equilibrium

[T,x_s] If $\underline{t} = 1$, the next two words are interpreted as temperature (K, °F) and static quality in equilibrium condition. Enter boron in W4 if needed.

[P,x_s] If $\underline{t} = 2$, the next two words are interpreted as pressure (Pa, lb_f/in²) and static quality in equilibrium condition. Enter boron in W4 if needed.

[P,T] If $\underline{t} = 3$, the next two words are interpreted as pressure (Pa, lb_f/in²) and temperature (K, °F) in equilibrium condition. Enter boron in W4 if needed.

Two Components (Steam/Water/Air), Non-equilibrium

The following options are used for input of non-equilibrium two-phase and/or noncondensable states. In all cases, the criteria used for determining the range of values for static quality (x_s) are

Two-phase if $1.0\text{E-}9 \leq x_s \leq 0.99999999$,

Single phase if $x_s < 1.0 \text{ E-}9$ or $x_s > 0.99999999$

The static quality is given by $x_s = M_g / (M_g + M_f)$, where $M_g = M_s + M_n$.

[P,T,x_s] If $\underline{t} = 4$, the next three words are interpreted as pressure (Pa, lb_f/in²), temperature (K, °F), and static quality in equilibrium condition. Using this input option with static quality greater than 0.0 and less than or equal to 1.0, saturated noncondensables will result. Also, the temperature is restricted to be less than the saturation temperature at the input pressure. Setting static quality to 0.0 is used as a flag that will initialize the volume to all noncondensable (dry noncondensable) with no temperature restrictions. Static quality is reset to 1.0 using this dry noncondensable option. Enter boron in W5 if needed.

[T,x_s,x_n] If $\underline{t} = 5$, the next three words are interpreted as steam saturation temperature (K, °F), static quality, and noncondensable quality in equilibrium condition. Enter boron in W5 if

needed. Both the static and noncondensable qualities are restricted to be between 1.0×10^{-9} and 0.99999999. The liquid will be subcooled. The input temperature determines the steam partial pressure, and the total pressure may be greater than the critical pressure, which will cause an input processing error. Little experience has been obtained using this option, and it has not been checked out.

[P,U_f,U_g, α_g ,x_n] If $\underline{t} = 6$, the next five words are interpreted as pressure (Pa, lb_f/in.²), liquid specific internal energy (J/kg, Btu/lb), vapor specific internal energy (J/kg, Btu/lb), vapor void fraction, and noncondensable quality. These quantities will be interpreted as nonequilibrium or equilibrium conditions depending on the internal energies used to define the thermodynamic state. The combinations of vapor void fraction and noncondensable quality must be thermodynamically consistent. If noncondensable quality is set to 0.0, noncondensables are not present and the input processing branches to that type of processing ($\underline{t} = 0$). If noncondensables are present (noncondensable quality greater than 0.0), then the vapor void fraction must also be greater than 0.0. If the noncondensable quality is set to 1.0 (pure noncondensable), then vapor void fraction must also be 1.0. When both the vapor void fraction and the noncondensable quality are set to 1.0, the volume temperature is calculated from the noncondensable energy equation using the input vapor-specific internal energy. Enter boron in W7 if needed.

W2-W7(R) Quantities as described under Word 1. Depending on the control word, 2-6 quantities may be required. Enter only the minimum number required. If entered, boron concentration (mass of boron per mass of liquid) follows the last required word for thermodynamic conditions.

8.10.8 Branch Junction Geometry, CCCN101-N109

These cards are required if n_j is greater than 0. cards with N equal to 1-9 are entered, one for each junction. For a BRANCH component, N need not be consecutive, but n_j cards must be entered. The card format for Words 1-6 is listed below and is identical to Words 1-6 on card CCC0101 of the Single-Junction Geometry Card, except that N instead of 0 is used in the fourth digit.

W1(I) From connection code to a component. This refers to the component from which the junction coordinate direction originates. The connection code is CCCVV000N, where CCC is the component number, VV is the volume number, and N indicates the face number. The number N equal to 1 and 2 specifies the inlet and outlet faces respectively for the volume's coordinate direction. The number N equal to 3-6 specifies crossflow. The number N equal to 3 and 4 would specify inlet and outlet faces for the second coordinate direction; N equal to 5 and 6 would do the same for the third coordinate direction. For connecting to a time-dependent volume, N is restricted to 1 or 2.

W2(I) To connection code to a component. This refers to the component at which the junction coordinate direction ends. See the description for W1 above.

- W3(R) Area (m^2 , ft^2). If 0, the area is set to the minimum area of the adjoining volumes. For abrupt area changes, the junction area must be equal to or smaller than the minimum of the adjoining areas. For smooth area changes, there are no restrictions.
- W4(R) Reynolds number independent forward flow energy loss coefficient, A_F . This quantity will be used in each of the phasic momentum equations when the junction velocity of that phase is positive or 0. A variable loss coefficient may be specified (see Section 8.10.10). The interpretation and use of this loss coefficient vary based upon the “a” junction control flag selected in W6. If the smooth area change option is selected ($a = 0$), the entry here is the loss coefficient appropriate for the junction flow area resulting from the entry made in W3. If one of the abrupt area change options is selected ($a = 1$ or 2), the entry here is the loss coefficient appropriate for the minimum flow area between the two hydrodynamic volumes connected by this junction. If the $a = 1$ option is selected, a loss coefficient entered here is considered to be additive with the abrupt area change flow energy loss coefficient, which is calculated separately by the code.
- W5(R) Reynolds number independent reverse flow energy loss coefficient, A_R . This quantity will be used in each of the phasic momentum equations when the junction velocity of that phase is negative. A variable loss coefficient may be specified (see Section 8.10.10). See information for the previous word regarding interpretation and use of this loss coefficient.
- W6(I) Junction control flags. This word has the format jefvcahs. For the branch component, the junction control flag is limited to the format 0efvcahs.
- e-flag The digit e specifies the modified PV term in the energy equations. $\underline{e} = 0$ means that the modified PV term will not be applied, and $\underline{e} = 1$ means that it will be applied.
- f-flag The digit f specifies CCFL options. $\underline{f} = 0$ means that the CCFL model will not be applied, and $\underline{f} = 1$ means that the CCFL model will be applied.
- v-flag The digit v specifies horizontal stratification entrainment/pullthrough options. This model is for junctions connected to a horizontal volume. $\underline{v} = 0$ means the model is not applied; $\underline{v} = 1$ means an upward oriented junction (offtake volume must be vertical); $\underline{v} = 2$ means a downward oriented junction (offtake volume must be vertical); and $\underline{v} = 3$ means a centrally (side) located junction.
- c-flag The digit c specifies choking options. $\underline{c} = 0$ means that the choking model will be applied, and $\underline{c} = 1$ means that the choking model will not be applied.
- The choking model used is based on input on card 1. If card 1 is missing or it does not contain Option 50, the Henry-Fauske critical flow model is active. If card 1 is present and it contains Option 50, the original RELAP5 critical flow model is active.

- a-flag** The digit a specifies area change options. a = 0 means a smooth area change and only the user supplied K_{loss} is applied. a = 1 means full abrupt area change model and the code calculates forward and reverse contraction/expansion K_{loss} terms and adds them to the user supplied K_{loss} terms. In addition, the code includes extra interphase drag to account for the vena contracta. a = 2 means a partial abrupt area change model and it is the same as a = 1 except no code calculated forward and reverse contraction/expansion K_{loss} is applied.
- h-flag** The digit h specifies nonhomogeneous or homogeneous. h = 0 specifies the nonhomogeneous (two-velocity momentum equations) option and h = 1 or 2 specifies the homogeneous (single-velocity momentum equation) option. For the homogeneous option (h = 1 or 2), the major edit printout will show h = 1.
- s-flag** The digit s specifies momentum flux options. s = 0 uses momentum flux in both the to and the from volume. s = 1 uses momentum flux in the from volume, but not in the to volume. s = 2 uses momentum flux in the to volume, but not in the from volume. s = 3 does not use momentum flux in either the to volume or the from volume.
- W7(R)** The meaning of this word is different, depending on the critical flow model which has been selected (see W6).
- If the Henry-Fauske critical flow model is active, the discharge coefficient is entered. If W7 and W8 are missing, W7 is set to 1.0 and W8 is set to 0.14.
- If the original RELAP5 critical flow model is active, the subcooled discharge coefficient is entered. This entry applies only to subcooled liquid choked flow calculations. The entry must be > 0.0 and < 2.0. If W7, W8 and W9 are missing, they are each set to 1.0.
- W8(R)** The meaning of this word is different, depending on the critical flow model which has been selected (see W6).
- If the Henry-Fauske critical flow model is active, the thermal nonequilibrium constant is entered. If W7 is entered and W8 is missing, W8 is set to 0.14. If the entry is < 0.01, the equilibrium option is used and W8 is reset to 0.0. If the entry is > 1000.0, the frozen option is used and W8 is reset to 100.0.
- If the original RELAP5 critical flow model is active, the two-phase discharge coefficient is entered. This entry applies only to two-phase choked flow calculations. The entry must be > 0.0 and < 2.0. If W7 is entered and W8 and W9 are missing, W8 and W9 are each set to 1.0.
- W9(R)** If the Henry-Fauske critical flow model is active, this word is not used and should not be entered.

If the original RELAP5 critical flow model is active, the superheated discharge coefficient is entered. This entry applies only to superheated vapor choked flow calculations. The entry must be > 0.0 and < 2.0 . If W7 and W8 are entered and W9 is missing, then W9 is set to 1.0.

8.10.9 Branch Junction Diameter and CCFL Data, CCCN110

These cards are optional. The value N should follow the same approach as used in cards CCCN101-N109. The defaults indicated for each word are used if the card is not entered. If these cards are being used to specify only the junction hydraulic diameter for the interphase drag calculations (i.e., $\underline{f} = 0$ in Word 6 of cards CCCN101-N109), then the diameter should be entered in Word 1 and any allowable values should be entered in Words 2-4 (will not be used). If these cards are being used for the CCFL model (i.e., $\underline{f} = 1$ in Word 6 of cards CCCN101-N109), then enter all four words for the appropriate CCFL model if values different from the default values are desired.

- W1(R) Junction hydraulic diameter, D_j (m, ft). This quantity is the junction hydraulic diameter used in the CCFL correlation equation and interphase drag. This number must be ≥ 0 . This number should be computed from $4.0 \cdot \left(\frac{\text{area}}{\text{wetted perimeter}} \right)$. If a 0 is entered or if the default is used, the junction diameter is computed from $2.0 \cdot \left(\frac{\text{area}}{\pi} \right)^{0.5}$ of the respective junction. See Word 3 of cards CCCN101-N109 for the junction area.
- W2(R) Flooding correlation form, β . If 0, the Wallis CCFL form is used. If 1, the Kutateladze CCFL form is used. β between 0.0 and 1.0, Bankoff weighting between the Wallis and Kutateladze CCFL forms is used. This number must be ≥ 0 and ≤ 1 . The default value is 0 (Wallis form).
- W3(R) Gas intercept, c . This quantity is the gas intercept used in the CCFL correlation (when $H_f^{1/2} = 0$) and must be > 0 . The default value is 1.
- W4(R) Slope, m . This quantity is the slope used in the CCFL correlation and must be > 0 . The default value is 1.

8.10.10 Branch Junction Form Loss Data, CCCN112

These cards are optional. The values of N should follow the same approach as used in cards CCCN101-N109. The user-specified form loss is given in Words 4 and 5 of cards CCCN101-N109 if these cards are not entered. If these cards are entered, the form loss coefficient is calculated from

$$K_F = A_F + B_F \text{Re}^{-C_F}$$

$$K_R = A_R + B_R \text{Re}^{-C_R}$$

where K_F and K_R are the forward and reverse form loss coefficient. A_F and A_R are the Words 4 and 5 of cards CCCN101-N109. Re is the Reynolds number based on mixture fluid properties. If these cards are being used for the form loss calculation, then enter all four words for the appropriate expression. See the discussion regarding the flow area basis assumed for A_F and A_R ; the same information applies for B_F and B_R .

W1(R) $B_F (\geq 0)$. This quantity must be greater than or equal to 0.

W2(R) $C_F (\geq 0)$. This quantity must be greater than or equal to 0.

W3(R) $B_R (\geq 0)$. This quantity must be greater than or equal to 0.

W4(R) $C_R (\geq 0)$. This quantity must be greater than or equal to 0.

8.10.11 Branch Junction Initial Conditions, CCCN201

These cards are required depending on the value of n_j as described for cards CCCN101-N109. The values of N should follow the same approach as used in cards CCCN101-N109.

W1(R) Initial liquid or mass flow (velocity in m/s, ft/s or mass flow in kg/s, lb/s).

W2(R) Initial vapor velocity or mass flow (velocity in m/s, ft/s or mass flow in kg/s, lb/s).

W3(R) Interface velocity (m/s, ft/s). Enter 0.

8.11 Separator Component, SEPARATR

A steam separator component is indicated by SEPARATR for Word 2 on card CCC0000. The connection code is CCCVV000N, where CCC is the component number, VV is the volume number, and N is the face number. For major edits, minor edits, and plot variables, the volume is numbered as CCC010000. The junctions associated with the separator component are numbered as CCCJJ0000, where JJ is the junction number ($01 \leq JJ \leq 03$).

A separator component is a specialized branch component having three junctions. The number of junctions n_j defined below must be 3, and no junctions may connect to this component. The variable N defined below must have values of 1, 2, and 3. For the junctions, $N = 1$ is the vapor outlet junction, $N = 2$ is the liquid fall back junction, and $N = 3$ is the separator inlet junction. The from part of the vapor outlet junction must refer to the outlet of the separator (CCC010002), and the from part of the liquid fall back must refer to the inlet of the separator (CCC010001). To include the direct path from a steam generator downcomer to the steam dome, a bypass volume is recommended. The smooth or abrupt junction option