

StepsHint field from the [Distributed Compliance Ledger](#). Commissioners SHOULD use this information to guide the user for this case.

- When commissioning fails, the commissioner MAY also reference [Distributed Compliance Ledger](#) fields such as CommissioningFallbackUrl (see [Section 5.7.5, “Commissioning Fallback Mechanism”](#)), UserManualUrl, SupportUrl and ProductUrl to assist the user in further steps to resolve the issue(s).
- The [Section 11.23, “Distributed Compliance Ledger”](#) entries for Standard Commissioning Flow devices SHALL include the [Section 11.23.6.8, “CommissioningCustomFlow”](#) field set to '0 - Standard' and the [Section 11.23.6.10, “CommissioningModeInitialStepsHint”](#) field set to a non-zero integer value, with bit 0 (Power Cycle) being set to 1. The [Section 11.23.6.11, “CommissioningModeInitialStepsInstruction”](#) field SHALL be set when CommissioningModeInitialStepsHint has a mandatory Pairing Instruction dependency and MAY be set when CommissioningModeInitialStepsHint has an optional Pairing Instruction dependency.

Table 78. Values of Ledger fields to represent Standard Commissioning Flow

Field Name	Value(s)
CommissioningCustomFlow	0 - Standard (Mandatory)
CommissioningModeInitialStepsHint	This field SHALL be set to a non-zero integer value. See Table 5, “Pairing and Reset Hint Values” for a complete list of pairing instructions. Example value: 33 - The following bits are set: 0 (Power Cycle - Mandatory), 5 (Device Manual - Optional). Bit 1 (Device Manufacturer URL) MAY be set.
CommissioningModeInitialStepsInstruction	The field SHALL be set when CommissioningModeInitialStepsHint has a mandatory Pairing Instruction dependency and MAY be set when CommissioningModeInitialStepsHint has an optional Pairing Instruction dependency. See PI Dependency column of Pairing Hint Table to determine which pairing hints have a mandatory or optional Pairing Instruction dependency and therefore require or allow this field to be populated.

5.7.2. User-Intent Commissioning Flow

- A User-Intent Commissioning Flow device SHALL be available for initial commissioning by any Matter commissioner.
- A User-Intent Commissioning Flow device, when in factory-new state, SHALL NOT start advertising automatically upon application of power (see [Section 5.4.2.2, “Announcement Commencement”](#)).
- To place a User-Intent Commissioning Flow device into advertising mode, some form of user interaction with the device beyond application of power is required (see [Table 5, “Pairing and](#)