

5.8. In-field Upgrade to Matter

This (informative) section discusses the case of a pre-Matter device currently in the user's home which gets software updated to support Matter, and which steps (either Matter-specified or manufacturer specific) would typically be applied to accomplish this goal.

- The initial situation is a device which is connected to the local network, and some manufacturer specific means (e.g. a manufacturer-provided app) is used to provide new firmware (including Matter functionality) to the device, along with the associated [Certification Declaration](#). Also, a unique [Device Attestation Certificate](#) is provided into the device using secure, manufacturer-specific means.
- The device restarts to enable the new firmware, and is now an uncommissioned Matter device.
- The device can be commissioned by any Commissioner; the [Onboarding Payload](#) needs to be provided to that Commissioner (since this information is not provided on or with the device out of the factory).
 - For this, similar mechanisms as discussed as in [Section 5.6.3, “Enhanced Commissioning Method \(ECM\)”](#) can be employed:
 - information equivalent to the parameters of the [OpenCommissioningWindow](#) command is sent to the device using some secure manufacturer-defined means
 - presentation of the Onboarding Payload and other relevant information can be performed using the mechanisms described in [Section 5.6.3.1, “Presentation of Onboarding Payload for ECM”](#).
 - For devices with a means to output the [Onboarding Payload](#) themselves (e.g. device with a display or audio output), alternatively, similar mechanisms as discussed as in [Section 5.6.2, “Basic Commissioning Method \(BCM\)”](#) can be employed:
 - information equivalent to the parameters of the [OpenBasicCommissioningWindow](#) command is sent to the device using some secure manufacturer-defined means
 - the device itself presents [Onboarding Payload](#).

5.9. Network Recovery

The operational network credentials (e.g., network name, password) can be changed after a node has been commissioned (see [Section 5.5, “Commissioning Flows”](#)). If this occurs, a Node might no longer be able to access its operational network. In that situation, the Node and an Administrator can execute a sequence of steps, called Network Recovery, to allow the Node to attempt to re-establish network connectivity.

Support for Network Recovery is optional and is indicated via the Network Recovery feature bit being set in the FeatureMap attribute of the General Commissioning Cluster.

NOTE | Support for Network Recovery flows is provisional.