

```

    subject-key-id    = 9F 55 A2 6B 7E 43 03 E6 08 83 E9 13 BF 94 F4 FB
                        5E 2A 61 61,
    authority-key-id  = 53 52 D7 05 9E 9C 15 A5 08 90 68 62 86 48 01 A2
                        9F 1F 41 D3,

  ]],
  signature          = 79 55 C2 02 63 0B 4B A4 D5 91 25 26 32 2F DF 28
                        F8 9E DF E5 AF 9C 0E 57 2B D8 A1 4A AA BB 4D 12
                        B8 3C A1 7C 7B 05 FB 16 4B 77 D7 9C 52 96 13 31
                        6B CF D1 78 95 E4 B2 A4 F2 40 4B 98 17 32 71 59
}

```

6.6. Access Control

6.6.1. Scope and Purpose

This section specifies the features related to controlling access to a Node's Endpoint Clusters ("Targets" hereafter) from other Nodes. The overall features are collectively named "Access Control" hereafter.

The Access Control features aim to ensure that only authorized Nodes are permitted access to given application-layer functionality exposed by the Data Model, through the Interaction Model. Access Control is the fundamental link between the Secure Channel and the Interaction Model.

In order to implement a policy of Access Control, Administrators on the fabric create and maintain a consistent distributed configuration of Access Control Lists (ACLs) across all Nodes. Each Node has an ACL containing Access Control Entries which codify the policy. The Access Control Cluster exposes a data model view of a Node's ACL which enables its maintenance. In addition to the ACL, a per-fabric [Access Restriction List](#) (ARL), which is set by the device, MAY exist. The ARL contains Access Restriction Entries, which identify the attributes, commands and events on specific endpoint clusters which are not accessible on a given fabric. The Access Control Cluster exposes a data model view of a Node's ARL, which enables its discovery.

6.6.2. Model

The Access Control system is rule-based with no implicit access permitted by default. Access to a Node's Targets is denied unless the Access Control system grants the required privilege level to a given Subject to interact with given Targets on that Node. Initial Access Control privileges are [bootstrapped](#) during the commissioning phase, and maintained thereafter by Administrators.

All access privileges, from the [AccessControlEntryPrivilegeEnum](#) enumeration, SHALL be granted by Access Control. Thus, the Initiator ("Subject" hereafter) of any Interaction Model action SHALL NOT succeed in executing a given action on a Node's Target unless that Node's Access Control system explicitly grants the required privilege to that Subject for that particular action.

The Access Control system grants privileges by checking and verifying all attempted access against rules explicitly codified in Access Control Entries within the Node's Access Control List and its Access Restriction List. Additionally, Access Control implicitly grants administrative access privi-