

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0018	ConfigurationVersion						P, O

Since this cluster has been derived from the [Basic Information](#) Cluster, the identifiers of the attributes, their range, quality and default characteristics and their descriptions correspond to those in that Cluster and those descriptions are not repeated here. Several attributes from the Basic Information Cluster which are *not* relevant or applicable for a Bridged Device have been marked with X in column Conformance and SHALL NOT be used in the Bridged Device Basic Information Cluster. The Conformance characteristics of several attributes in this cluster have changed from M to O compared to their Conformance in the Basic Information Cluster, and SHALL be used according to the table above.

9.13.5.1. VendorName, VendorID & ProductID Attributes

The Bridge SHOULD fill these attributes with the available information, which could e.g. come from the Bridged Device provided to the Bridge over the non-Matter interface (e.g. VendorName and VendorID) or could have been provided by the user (e.g. assigned name of a device for NodeLabel).

If the manufacturer of a Bridged Device is known to the Bridge, the Bridge SHALL provide this name (in attribute VendorName), otherwise it SHALL NOT include this attribute.

If the manufacturer of a Bridged Device and the associated Alliance-assigned [Vendor ID](#) are known to the Bridge (e.g. by copying the Manufacturer Code from the Node Descriptor of a Zigbee device or the Basic Information cluster of a Matter device), the Bridge SHALL provide this identifier (in attribute VendorID), otherwise it SHALL NOT include this attribute. If the associated [Product ID](#) of a bridged Matter device is known to the Bridge (e.g. from the Basic Information cluster of the bridged Matter device), the Bridge SHALL provide this identifier (in attribute ProductID), otherwise it SHALL NOT include this attribute. For bridged non-Matter devices, the ProductID attribute SHALL NOT be included.

9.13.5.2. Reachable Attribute

This attribute SHALL be used to indicate whether the bridged device is reachable by the bridge, so a Matter Node which wants to communicate with a bridged device can get an indication that this might fail (when the attribute is False). Determination of reachability might not be perfect (e.g. depending on technology employed), so the Matter Node SHOULD be aware of the risk of false positives and negatives on reachability determination. For example, a bridged device MAY be marked as unreachable while it could actually be reached, and vice-versa. Also, detection (and indication) that a bridged device is not longer reachable may be delayed due to the technique employed (e.g. detecting that a number of expected messages from the bridged device did not arrive). Also see event ReachableChanged below.

9.13.5.3. UniqueID Attribute

This attribute SHALL, for a Bridged Device, be updated when the Bridge is factory reset. If the bridged device does not provide some unique id (e.g. in the case of bridging from non-Matter devices, or in case of bridging Matter devices from an earlier revision which were not required to