

11.1.5.23. MaxPathsPerInvoke Attribute

This attribute SHALL indicate the maximum number of elements in a single InvokeRequests list (see [Section 8.8.2, “Invoke Request Action”](#)) that the Node is able to process. Note that since this attribute MAY change over time, both increasing and decreasing, as software versions change for a given Node, clients SHOULD take care not to assume forever unchanging values and SHOULD NOT cache this value permanently at Commissioning time.

If the **MaxPathsPerInvoke** attribute is absent or zero, such as in Basic Information cluster revisions prior to Revision 3, clients SHALL assume a value of 1.

11.1.5.24. ConfigurationVersion Attribute

This attribute SHALL contain the current version number for the configuration of the Node. A larger value of ConfigurationVersion SHALL indicate a newer configuration than a lower value.

11.1.6. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	StartUp	CRITICAL		V	M
0x01	ShutDown	CRITICAL		V	O
0x02	Leave	INFO		V	O
0x03	Reach-ableChanged	INFO		V	Reachable

11.1.6.1. StartUp Event

The StartUp event SHALL be generated by a Node as soon as reasonable after completing a boot or reboot process. The StartUp event SHOULD be the first Data Model event recorded by the Node after it completes a boot or reboot process.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Software-Version	uint32				M

SoftwareVersion Field

This field SHALL be set to the same value as the one available in the [SoftwareVersion](#) attribute.

11.1.6.2. ShutDown Event

The ShutDown event SHOULD be generated by a Node prior to any orderly shutdown sequence on a best-effort basis. When a ShutDown event is generated, it SHOULD be the last Data Model event recorded by the Node. This event SHOULD be delivered urgently to current subscribers on a best-effort basis. Any subsequent incoming interactions to the Node MAY be dropped until the comple-