

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0018	BatCapacity	uint32	all	F		R V	[REPLC RECHG]
0x0019	BatQuantity	uint8	all	F		R V	REPLC
0x001A	BatCharge State	BatChargeStateEnum	desc			R V	RECHG
0x001B	Bat-TimeTo-FullCharge	uint32	all	Q X		R V	[RECHG]
0x001C	BatFunctional-WhileCharging	bool	all			R V	RECHG
0x001D	BatChargingCurrent	uint32	all	C X		R V	[RECHG]
0x001E	Active-BatCharge Faults	list[BatChargeFaultEnum]	max 16			R V	[RECHG]
0x001F	EndpointList	list[endpoint-no]				R V	M

11.7.7.1. Status Attribute

This attribute SHALL indicate the participation of this power source in providing power to the Node as specified in [PowerSourceStatusEnum](#).

11.7.7.2. Order Attribute

This attribute SHALL indicate the relative preference with which the Node will select this source to provide power. A source with a lower order SHALL be selected by the Node to provide power before any other source with a higher order, if the lower order source is available (see [Section 11.7.7.1, “Status Attribute”](#)).

Note, Order is read-only and therefore NOT intended to allow clients control over power source selection.

11.7.7.3. Description Attribute

This attribute SHALL provide a user-facing description of this source, used to distinguish it from other power sources, e.g. "DC Power", "Primary Battery" or "Battery back-up". This attribute SHALL NOT be used to convey information such as battery form factor, or chemistry.