

NetworkIndex Field

This field SHALL contain the 0-based index of the entry in the [Networks](#) attribute that was last added, updated or removed successfully by the associated request command.

11.9.7.8. ConnectNetwork Command

This command is used to connect to a network on the network interface associated with the cluster instance.

This command SHALL attempt to connect to a network whose configuration was previously added by either the [AddOrUpdateWiFiNetwork](#) or [AddOrUpdateThreadNetwork](#) commands. Network is identified by its NetworkID.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NetworkID	octstr	1 to 32			M
1	Bread-crumbs	uint64	all			O

This command SHALL fail with a BUSY status code returned to the initiator if the server is currently unable to proceed with such an operation, such as if it is currently attempting to connect in the background, or is already proceeding with a prior ConnectNetwork.

If this command is received without an armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)), then this command SHALL fail with a FAILSAFE_REQUIRED status code sent back to the initiator.

Before connecting to the new network, the Node SHALL disconnect the operational network connections managed by any other Network Commissioning cluster instances (whether under the Root Node or a Secondary Network Interface), where those connections are not represented by an entry in the Networks attribute of the corresponding cluster instance. This ensures that an Administrator or Commissioner can reliably reconfigure the operational network connection of a device that has one or more Secondary Network interfaces, for example by removing the active network configuration from one cluster instance, followed by adding a new configuration and calling ConnectNetwork on a different cluster instance.

Success or failure of this command SHALL be communicated by the ConnectNetworkResponse command, unless some data model validations caused a FAILURE status to be sent prior to finishing execution of the command. The ConnectNetworkResponse SHALL indicate the value Success in the NetworkingStatus field on successful connection. On failure to connect, the ConnectNetworkResponse SHALL contain an appropriate NetworkingStatus, DebugText and ErrorValue indicating the reason for failure.

The amount of time needed to determine successful or failing connectivity on the cluster server’s associated interface is provided by the [ConnectMaxTimeSeconds](#) attribute. Clients SHALL NOT consider the connection to have timed-out until at least that duration has taken place. For non-concurrent commissioning situations, the client SHOULD allow additional margin of time to account for its delay in executing [operational discovery](#) of the Node once it is connected to the new network.