

error and the [RegulatoryConfig](#) attribute and associated internal radio configuration SHALL remain unchanged.

If the [LocationCapability](#) attribute is set to Indoor/Outdoor, then the [RegulatoryConfig](#) attribute SHALL be set to match the NewRegulatoryConfig field.

On successful execution of the command, the ErrorCode field of the [SetRegulatoryConfigResponse](#) SHALL be set to OK.

The Breadcrumb field SHALL be used to atomically set the [Breadcrumb](#) attribute on success of this command, when SetRegulatoryConfigResponse has the ErrorCode field set to OK. If the command fails, the [Breadcrumb](#) attribute SHALL be left unchanged.

11.10.7.5. SetRegulatoryConfigResponse Command

This command is used to report the result of the SetRegulatoryConfig command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ErrorCode	CommissioningErrorEnum			OK	M
1	DebugText	string			""	M

ErrorCode Field

This field SHALL contain the result of the operation, based on the behavior specified in the functional description of the SetRegulatoryConfig command.

DebugText Field

See [Section 11.10.7.1, “Common fields in General Commissioning cluster responses”](#).

11.10.7.6. CommissioningComplete Command

This command is used to indicate that the commissioning process is complete.

Success or failure of this command SHALL be communicated by the [CommissioningCompleteResponse](#) command, unless some data model validations caused a failure status code to be issued during the processing of the command.

This command signals the Server that the Commissioner or Administrator has successfully completed all steps needed during the Fail-Safe period, such as commissioning (see [Section 5.5, “Commissioning Flows”](#)) or other Administrator operations requiring usage of the Fail Safe timer. It ensures that the Server is configured in a state such that it still has all necessary elements to be fully operable within a Fabric, such as ACL entries (see [Section 9.10, “Access Control Cluster”](#)) and operational credentials (see [Section 6.4, “Node Operational Credentials Specification”](#)), and that the Node is reachable using CASE (see [Section 4.14.2, “Certificate Authenticated Session Establishment \(CASE\)”](#)) over an operational network.