

0x0C	SetVIDVerificationStatement	client $\Rightarrow$ server	Y	A F	M
0x0D	SignVIDVerificationRequest	client $\Rightarrow$ server	SignVIDVerificationResponse	A	M
0x0E	SignVIDVerificationResponse	client $\leftarrow$ server	N		M

NOTE

The SetVIDVerificationStatement, SignVIDVerificationRequest and SignVIDVerificationResponse commands appeared and were made mandatory in cluster revision 2, in specification version 1.4.2. Prior revisions of this cluster's servers will NOT have the necessary commands. Clients SHOULD use the AcceptedCommandList and GeneratedCommandList global attributes, and/or the cluster revision, to determine support of the feature, if they intend to rely on it.

11.18.6.1. AttestationRequest Command

This command is used to perform an attestation request.

This command SHALL be generated to request the [Attestation Information](#), in the form of an [AttestationResponse Command](#). If the AttestationNonce that is provided in the command is malformed, a recipient SHALL fail the command with a Status Code of INVALID_COMMAND. The Attestation-Nonce field SHALL be used in the computation of the Attestation Information.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Attestation-Nonce	octstr	32			M

11.18.6.2. AttestationResponse Command

This command is used to report the results of the AttestationRequest command. This command SHALL be generated in response to an [Attestation Request command](#).

See [Section 11.18.4.7, “Attestation Information”](#) for details about the generation of the fields within this response command.

See [Section F.2, “Device Attestation Response test vector”](#) for an example computation of an AttestationResponse.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	AttestationElements	octstr	max RESP_-MAX			M