

It provides status information about the success or failure of those commands.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StatusCode	NodeOperationalCert-StatusEnum				M
1	FabricIndex	fabric-idx	1 to 254			StatusCode == OK, O
2	DebugText	string	max 128			O

StatusCode Field

This field SHALL contain an [NOCStatus](#) value representing the status of an operation involving a [NOC](#).

FabricIndex Field

If present, it SHALL contain the Fabric Index of the Fabric last added, removed or updated.

DebugText Field

This field MAY contain debugging textual information from the cluster implementation, which SHOULD NOT be presented to user interfaces in any way. Its purpose is to help developers in troubleshooting errors and the contents MAY go into logs or crash reports.

11.18.6.11. UpdateFabricLabel Command

This command is used to set the user-visible fabric label for a given Fabric.

This command SHALL be used by an Administrator to set the user-visible [Label](#) field for a given Fabric, as reflected by entries in the [Fabrics](#) attribute. An Administrator SHALL use this command to set the Label to a string (possibly selected by the user themselves) that the user can recognize and relate to this Administrator

- during the commissioning process, and
- whenever the user chooses to update this string.

The Label field, along with the VendorID field in the same entry of the Fabrics attribute, SHOULD be used by Administrators to provide additional per-fabric context when operations such as Remove-Fabric are considered or used.

Access Modifier: Fabric Scoped						
ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Label	string	max 32			M