

### 11.22.5.2. SendAccept Message

A **SendAccept** message is sent by the Responder as a response to **SendInit** in order to accept a BDX Transfer session where the Initiator wants to be a Sender and deliver information (upload) to the Responder. The final transfer parameters used are decided by the Responder, given the Initiator proposals in the **SendInit** message.

Responds to (See [Section 11.22.7, “Synchronous Transfers Message Flows”](#) for examples):

- **SendInit** - to accept the proposed transfer.

Possible replies (See [Section 11.22.7, “Synchronous Transfers Message Flows”](#) for examples):

- **Block** - if the Initiator accepts the parameters from the **SendAccept** message, and the transfer method is Sender drive.
- **StatusReport** - If there was another error the Initiator encountered.

Possible follow-ups (See [Section 11.22.7, “Synchronous Transfers Message Flows”](#) for examples):

- **BlockQuery** - if the proposed method is Receiver drive. If the Initiator does not accept the parameters, it SHOULD ignore this and send a **StatusReport(GeneralCode: FAILURE, ProtocolId: BDX, ProtocolCode: TRANSFER\_METHOD\_NOT\_SUPPORTED)** to end the transfer.

### 11.22.5.3. ReceiveAccept Message

A **ReceiveAccept** message is sent by the Responder as a response to **ReceiveInit** in order to accept a BDX Transfer session where the Initiator wants to be a Receiver and receive information (download) from the Responder. The final transfer parameters used are decided by the Responder, given the Initiator proposals in the **ReceiveInit** message.

Responds to (See [Section 11.22.7, “Synchronous Transfers Message Flows”](#) for examples):

- **ReceiveInit** - to accept the proposed transfer.

Possible replies (See Message Flows for examples):

- **BlockQuery** - if the Initiator accepts the parameters from the **ReceiveAccept** message, and the transfer method is Receiver drive.
- **StatusReport** - If there was another error the Initiator encountered.

Possible follow-ups (See [Section 11.22.7, “Synchronous Transfers Message Flows”](#) for examples):

- **Block** - if the proposed method is Sender drive. If the Initiator does not accept the parameters, it SHOULD ignore this and send a **StatusReport(GeneralCode: FAILURE, ProtocolId: BDX, ProtocolCode: TRANSFER\_METHOD\_NOT\_SUPPORTED)** to end the transfer.

### 11.22.5.4. SendAccept and ReceiveAccept message fields

The format of the **SendAccept** message is enumerated in [Table 113, “SendAccept message fields”](#).

The format of the **ReceiveAccept** message is enumerated in [Table 114, “ReceiveAccept message](#)