

11.24.6.14. NodeEndpointList Attribute

This SHALL indicate the Endpoint entries for nodes in the accessing fabric.

Any changes to this List (add/remove entry) must follow the pending → committed workflow with current state reflected in the Status Entry.

11.24.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	AddKeySet	Client ⇒ Server	Y	A	P, M
0x01	UpdateKeySet	Client ⇒ Server	Y	A	P, M
0x02	RemoveKey-Set	Client ⇒ Server	Y	A	P, M
0x03	AddGroup	Client ⇒ Server	Y	A	P, M
0x04	UpdateGroup	Client ⇒ Server	Y	A	P, M
0x05	RemoveGroup	Client ⇒ Server	Y	A	P, M
0x06	AddAdmin	Client ⇒ Server	Y	A	P, M
0x07	UpdateAdmin	Client ⇒ Server	Y	A	P, M
0x08	RemoveAdmin	Client ⇒ Server	Y	A	P, M
0x09	AddPendingN-ode	Client ⇒ Server	Y	A	P, M
0x0A	RefreshNode	Client ⇒ Server	Y	A	P, M
0x0B	UpdateNode	Client ⇒ Server	Y	A	P, M
0x0C	RemoveNode	Client ⇒ Server	Y	A	P, M
0x0D	UpdateEnd-pointForNode	Client ⇒ Server	Y	A	P, M
0x0E	AddGroupID-ToEndpoint-ForNode	Client ⇒ Server	Y	A	P, M
0x0F	Remove-GroupID-FromEnd-pointForNode	Client ⇒ Server	Y	A	P, M
0x10	AddBinding-ToEndpoint-ForNode	Client ⇒ Server	Y	A	P, M
0x11	RemoveBind-ingFromEnd-pointForNode	Client ⇒ Server	Y	A	P, M