

ID	Name	Type	Constraint	Quality	Fallback	Conformance
1	NodeID	node-id	all			M
2	Friendly-Name	string	max 32			M
3	VendorID	vendor-id	all			M
4	ICAC	octstr	max 400			M

NodeID, FriendlyName, VendorID and ICAC represent the admin to be added to the [Joint Fabric](#) Datastore Cluster.

11.24.7.8. UpdateAdmin Command

This command SHALL be used to update an admin in the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all	X		M
1	Friendly-Name	string	max 32	X		M
2	ICAC	octstr	max 400	X		M

NodeID represents the admin to be updated in the [Joint Fabric](#) Datastore Cluster. NULL values for the additional parameters will be ignored (not updated).

If entry is not found, return NOT_FOUND.

11.24.7.9. RemoveAdmin Command

This command SHALL be used to remove an admin from the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all			M

NodeID represents the unique identifier for the admin to be removed from the [Joint Fabric](#) Datastore Cluster.

If entry is not found, return NOT_FOUND.