

11.24.7.20. RemoveACLFromNode Command

This command SHALL be used to remove an ACL from a node in the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ListID	uint16	all			M
1	NodeID	node-id	all			M

ListID represents the unique identifier for the [DatastoreACLEntryStruct](#) to be removed from the Datastore's list of DatastoreACLEntry.

NodeID represents the unique identifier for the node from which the ACL is to be removed.

Upon receipt of this command, the Datastore SHALL:

1. Confirm that a Node Information Entry exists for the given NodeID, and if not, return NOT_FOUND.
2. Ensure the ACL List for the given NodeID does not include the given ACLEntry. If it does:
 - a. Update the status to **DeletePending** for the given ACLEntry in the ACL List.
 - b. Remove this ACLEntry from the given Node ID.
 - i. If this succeeds, remove the given ACLEntry from the Node ACL List.
 - ii. If not successful, update the Status to **CommitFailed** and the FailureCode to the returned error. The error SHALL be handled in a subsequent [Node Refresh](#).

11.25. Joint Fabric Administrator Cluster

An instance of the Joint Fabric Administrator Cluster only applies to Joint Fabric Administrator nodes fulfilling the role of Anchor CA.

NOTE	Support for Joint Fabric Administrator Cluster is provisional.
-------------	--

11.25.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision