

If the command is not executed via a CASE session, the command SHALL fail with a status code of `UNSUPPORTED_ACCESS`.

The server MAY request approval from the user, but it is not required.

The server SHALL always return `SUCCESS` to a correctly formatted `RequestCommissioningApproval` command, and then generate a `CommissioningRequestResult` event associated with the command's accessing fabric once the result is ready.

Clients SHOULD avoid using the same `RequestID`. If the `RequestID` and client `NodeID` of a `RequestCommissioningApproval` match a previously received `RequestCommissioningApproval` and the server has not returned an error or completed commissioning of a device for the prior request, then the server SHOULD return `FAILURE`.

The parameters for `RequestCommissioningApproval` command are as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	RequestID	uint64				M
1	VendorID	vendor-id				M
2	ProductID	uint16				M
3	Label	string	max 64			O

11.26.6.2. RequestID

This SHALL be set by the client to be used again in future interactions.

11.26.6.3. VendorID / ProductID fields

These fields SHALL contain the `VendorID` and `ProductID` which match the values in the Device Attestation Certificate of the device that the client would like to have commissioned in the subsequent `ReverseOpenCommissioningWindow` command.

11.26.6.4. Label

The `Label` field SHOULD be set to a user readable name for the device that the client would like to have commissioned in the subsequent `ReverseOpenCommissioningWindow` command. This may be an ecosystem defined label or user provided name.

For example, in [FabricSynchronization](#) between two ecosystems (E1 as initial commissioner and E2 as initial commissionee), the label here represents the node on E1 that will be commissioned by E2 in the reverse commissioning operation after E1 has initially commissioned E2. This enables E2 to provide the user with a label for the node on E1 prior to completing the reverse commissioning operation.

11.26.6.5. CommissionNode Command

This command is sent by a client to request that the server begins commissioning a previously