

30:46:02:21:00:95:ff:.....

The ICA cross signing requires the Anchor Administrator to receive and validate the Certificate Signing Request. The validation steps are as follows:

1. ICAC CSR follows the encoding and rules from [PKCS #10](#).
2. Signature SHALL be validated using the [trusted SubjectPublicKey](#).
3. Convert the Subject Public Key Info of the ICA CSR to the equivalent Matter certificate TLV values by using the specific rules for [ec-pub-key](#), [pub-key-algo](#) and [ec-curve-id](#).
 - a. Values for [ec-pub-key](#), [pub-key-algo](#), [ec-curve-id](#) SHALL match with the ones of the [trusted SubjectPublicKey](#)
4. Upon success, ICA's certificate SHALL be signed by the root CA of the Anchor Administrator, such that the ICAC chains to the [RCAC](#) of the Anchor Administrator.
 - a. The subject DN SHALL encode a [matter-fabric-id](#) attribute. The attribute's value SHALL be identical to the Fabric ID of the Anchor Fabric.
5. ICAC SHALL be returned inside the [ICAC](#) field of the [Section 11.25.7.3, "AddICAC"](#) command. If any of the above validation checks fail, the server SHALL immediately terminate the procedure and inform the User.

12.2.6. Anchor Administrator Selection

The [Section 12.2, "Joint Fabric"](#) design allows devices to communicate with one another regardless of which commissioner was used to commission devices. Similarly, devices participating in Joint Fabric can be removed without impacting the remaining devices. If all devices commissioned using a particular commissioner are deleted, the devices remaining in the Joint Fabric will typically continue to function.

User SHALL provide consent when an Anchor Administrator is removed and a new Anchor CA is chosen. In the example below, the Anchor Administrator is removed from the Joint Fabric and the user has selected a candidate Administrator to be promoted to Anchor Administrator. For clarity, Joint Fabric Anchor Administrator [A](#) is being replaced with the candidate Joint Fabric Administrator [B](#).

User consent SHALL be mutual:

- on Administrator [A](#) side, User provides consent that transfer of the Anchor role to Administrator [B](#) is allowed.
- on Administrator [B](#) side, User provides consent that receipt of the Anchor role from Administrator [A](#) is allowed.

Flow for Anchor Transfer is as follows:

1. Administrator B SHALL:
 - a. send [TransferAnchorRequest](#) to Administrator A to set itself as Joint Fabric Anchor Administrator.