

GetGroupMembership command.

The GetGroupMembershipResponse command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Capacity	uint8	all	X		M
1	GroupList	list[group-id]	all[min 1]			M

1.3.7.9.1. Capacity Field

This field SHALL contain the remaining capacity of the Group Table of the node. The following values apply:

- 0 - No further groups MAY be added.
- $0 < \text{Capacity} < 0xFE$ - Capacity holds the number of groups that MAY be added.
- $0xFE$ - At least 1 further group MAY be added (exact number is unknown).
- null - It is unknown if any further groups MAY be added.

1.3.7.9.2. GroupList Field

The GroupList field SHALL contain either the group IDs of all the groups in the Group Table for which the server endpoint is a member of the group (in the case where the GroupList field of the received GetGroupMembership command was empty), or the group IDs of all the groups in the Group Table for which the server endpoint is a member of the group *and* for which the group ID was included in the the GroupList field of the received GetGroupMembership command (in the case where the GroupList field of the received GetGroupMembership command was not empty).

Zigbee: If the total number of groups will cause the maximum payload length of a frame to be exceeded, then the GroupList field SHALL contain only as many groups as will fit.

1.3.7.10. RemoveGroupResponse Command

The RemoveGroupResponse command is generated by the server in response to the receipt of a RemoveGroup command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	enum8	desc			M
1	GroupID	group-id	min 1			M

1.3.7.10.1. Status Field

This field is according to the Effect on Receipt section of the RemoveGroup command.

1.3.7.10.2. GroupID Field

This field is set to the GroupID field of the received RemoveGroup command.