

1.4.7.5.3. SceneName Field

The field is the name of the scene.

If scene names are not supported, any commands that write a scene name SHALL simply discard the name, and any command that returns a scene name SHALL return an empty string.

1.4.7.5.4. SceneTransitionTime Field

This field is the amount of time, in milliseconds, it will take for a cluster to change from its current state to the requested state.

1.4.7.5.5. ExtensionFields Field

See the Scene Table Extensions subsections of individual clusters. A Scene Table Extension SHALL only use attributes with the Scene quality. Each ExtensionFieldSetStruct holds a set of values of these attributes for a cluster implemented on the same endpoint where the Scene ("S") designation appears in the quality column. A scene is the aggregate of all such fields across all clusters on the endpoint.

1.4.8. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	DoNotUse					R V	X
0x0001	SceneTableSize	uint16	desc	F		R V	M
0x0002	FabricSceneInfo	list[SceneInfoStruct]	desc			R V F	M

1.4.8.1. SceneTableSize Attribute

This attribute SHALL indicate the number of entries in the [Scene Table](#) on this endpoint. This is the total across all fabrics; note that a single fabric cannot use all those entries (see [Handling of fabric-scoping](#)). The minimum size of this table, (i.e., the minimum number of scenes to support across all fabrics per endpoint) SHALL be 16, unless a device type in which this cluster is used, defines a larger value in the device type definition.

1.4.8.2. FabricSceneInfo Attribute

This attribute SHALL indicate a list of fabric scoped information about scenes on this endpoint.

The number of list entries for this attribute SHALL NOT exceed the number of supported fabrics by the device.

1.4.9. Commands