

1.6.4.1.2. Effect of Level Control Commands on the OnOff Attribute

There are two sets of commands provided in the Level Control cluster. These are identical, except that the first set (MoveToLevel, Move and Step commands) SHALL NOT affect the OnOff attribute, whereas the second set ('with On/Off' variants) SHALL.

The first set is used to maintain independence between the CurrentLevel and OnOff attributes, so changing CurrentLevel has no effect on the OnOff attribute. As examples, this represents the behavior of a volume control with a separate mute button, or a 'turn to set level and press to turn on/off' light dimmer.

The second set is used to link the CurrentLevel and OnOff attributes. When the level is reduced to its minimum the OnOff attribute is automatically turned to FALSE, and when the level is increased above its minimum the OnOff attribute is automatically turned to TRUE. As an example, this represents the behavior of a light dimmer with no independent on/off switch.

For the Stop command, the StopWithOnOff is included solely for symmetry, to allow easy choice of one or other set of commands – both Stop commands are identical, because the dependency on On/Off is determined by the original command that is being stopped.

1.6.4.1.3. Effect of Level Control Commands Depends on OnOff

Before the Options attribute was introduced, all commands except those postfixed with 'with On/Off', had no effect if the OnOff attribute of the On/Off cluster, on the same endpoint, was FALSE. Even if the On/Off (OO) feature set bit is set to zero, this is still true. To allow such commands to function, please see the Options attribute below.

1.6.4.1.4. GlobalSceneControl and Commands with On/Off

If a MoveToLevel(WithOnOff), Move(WithOnOff) or Step(WithOnOff) command is received that causes a change to the value of the OnOff attribute of the On/Off cluster, the value of the GlobalSceneControl attribute of the On/Off cluster SHALL be updated according to section [GlobalSceneControl](#).

1.6.4.2. Lighting Feature

This feature supports an interface for controlling the level of a light source.

For the CurrentLevel attribute:

A value of 0x00 SHALL NOT be used.

A value of 0x01 SHALL indicate the minimum level that can be attained on a device.

A value of 0xFE SHALL indicate the maximum level that can be attained on a device.

A value of null SHALL represent an undefined value.

All other values are application specific gradations from the minimum to the maximum level.

1.6.4.3. Frequency Feature

NOTE	The Frequency feature is provisional.
-------------	---------------------------------------