

attribute) SHALL be present in the scene table but ignored. An extension field set value outside of the accepted values of the corresponding MoveTo<Target> command, e.g. a null value for the CurrentLevel attribute, corresponding to the MoveToLevel command, SHALL be ignored.

1.6.6.2. CurrentLevel Attribute

This attribute SHALL indicate the current level of this device. The meaning of 'level' is device dependent.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once per second, or
- At the end of the movement/transition, or
- When it changes from null to any other value and vice versa.

1.6.6.3. RemainingTime Attribute

This attribute SHALL indicate the time remaining until the current command is complete - it is specified in 1/10ths of a second.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- When it changes from 0 to any value higher than 10, or
- When it changes, with a delta larger than 10, caused by the invoke of a command, or
- When it changes to 0.

For commands with a transition time or changes to the transition time less than 1 second, changes to this attribute SHALL NOT be reported.

As this attribute is not being reported during a regular countdown, clients SHOULD NOT rely on the reporting of this attribute in order to keep track of the remaining duration.

1.6.6.4. MinLevel Attribute

This attribute SHALL indicate the minimum value of CurrentLevel that is capable of being assigned.

1.6.6.5. MaxLevel Attribute

This attribute SHALL indicate the maximum value of CurrentLevel that is capable of being assigned.

1.6.6.6. CurrentFrequency Attribute

This attribute SHALL indicate the frequency at which the device is at CurrentLevel. A CurrentFrequency of 0 is unknown.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once per second, or