

1.6.6.10. OnOffTransitionTime Attribute

This attribute SHALL indicate the time taken to move to or from the target level when On or Off commands are received by an On/Off cluster on the same endpoint. It is specified in 1/10ths of a second.

The actual time taken SHOULD be as close to OnOffTransitionTime as the device is able. Please note that if the device is not able to move at a variable rate, the OnOffTransitionTime attribute SHOULD NOT be implemented.

1.6.6.11. OnLevel Attribute

This attribute SHALL indicate the value that the CurrentLevel attribute is set to when the OnOff attribute of an On/Off cluster on the same endpoint is set to TRUE, as a result of processing an On/Off cluster command. If the OnLevel attribute is not implemented, or is set to the null value, it has no effect. For more details see [Effect of On/Off Commands on the CurrentLevel attribute](#).

OnLevel represents a mandatory field that was previously not present or optional. Implementers should be aware that older devices may not implement it.

1.6.6.12. OnTransitionTime Attribute

This attribute SHALL indicate the time taken to move the current level from the minimum level to the maximum level when an On command is received by an On/Off cluster on the same endpoint. It is specified in 1/10ths of a second. If this attribute is not implemented, or contains a null value, the OnOffTransitionTime SHALL be used instead.

1.6.6.13. OffTransitionTime Attribute

This attribute SHALL indicate the time taken to move the current level from the maximum level to the minimum level when an Off command is received by an On/Off cluster on the same endpoint. It is specified in 1/10ths of a second. If this attribute is not implemented, or contains a null value, the OnOffTransitionTime SHALL be used instead.

1.6.6.14. DefaultMoveRate Attribute

This attribute SHALL indicate the movement rate, in units per second, when a Move command is received with a null value Rate parameter.

1.6.6.15. StartUpCurrentLevel Attribute

This attribute SHALL indicate the desired startup level for a device when it is supplied with power and this level SHALL be reflected in the CurrentLevel attribute. The values of the StartUpCurrentLevel attribute are listed below:

Value	Action on power up
0	Set the CurrentLevel attribute to the minimum value permitted on the device