

the sensor is no longer triggered, this attribute SHALL be set to the inactive state, by setting the bit to 0, for all supported alarm modes.

If an alarm mode is not supported, the bit indicating this alarm mode SHALL always be 0.

A bit SHALL indicate whether the alarm mode inactive or not:

- 0 = Inactive
- 1 = Active

1.8.6.5. AlarmsSuppressed Attribute

This attribute SHALL indicate which specific alarm modes on the server are currently suppressed. When the sensor is no longer triggered, this attribute SHALL be set to the unsuppressed state, by setting the bit to 0, for all supported alarm modes.

If an alarm mode is not supported, the bit indicating this alarm mode SHALL always be 0.

A bit SHALL indicate whether the alarm mode is suppressed or not:

- 0 = Not suppressed
- 1 = Suppressed

1.8.6.6. AlarmsEnabled Attribute

This attribute SHALL indicate the alarm modes that will be emitted if the sensor is triggered.

If an alarm mode is not supported, the bit indicating this alarm mode SHALL always be 0.

A bit SHALL indicate whether the alarm mode is enabled or disabled:

- 0 = Disabled
- 1 = Enabled

1.8.6.7. AlarmsSupported Attribute

This attribute SHALL indicate the alarms supported by the sensor.

A bit SHALL indicate whether the alarm mode is supported:

- 0 = Not supported
- 1 = Supported

1.8.6.8. SensorFault Attribute

This attribute SHALL indicate any faults registered by the device.

1.8.7. Commands