

ported list, the server SHALL set the **CurrentMode** attribute to the **NewMode** value, otherwise, the server SHALL respond with an **INVALID_COMMAND** status response.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NewMode	uint8	desc			M

1.10. Mode Base Cluster

This cluster provides an interface for controlling a characteristic of a device that can be set to one of several predefined values. For example, the light pattern of a disco ball, the mode of a massage chair, or the wash cycle of a laundry machine.

The server allows the client to set a mode on the server. A mode is one of a list of options that may be presented by a client for a user choice, or understood by the client, via the mode's tags.

A mode tag is either a standard tag within a standard category namespace, or a manufacturer specific tag, within the namespace of the vendor ID of the manufacturer.

Any derived cluster specification based on this cluster SHALL support the standard mode tag value definitions and command status definitions defined in this cluster and MAY define additional standard mode tag values and standard command status values that are supported in the respective derived cluster instances.

Each cluster ID that indicates this specification SHALL define a distinct purpose for the cluster instance. For example: A **LightBlinking** cluster ID supports blinking modes for a light (and is described that way).

An anonymous mode SHALL NOT replace the meaning of a standard mode tag, when one exists, for the cluster purpose.

1.10.1. Revision History

The global **ClusterRevision** attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	ChangeToModeResponse command: StatusText must be provided for InvalidInMode status. Require at least one standard mode tag. Define reserved ranges for base/derived clusters

1.10.2. Classification