

OnOff Change	CurrentMode Change
ON → OFF	No change
OFF → ON	Change CurrentMode to OnMode
OFF → OFF	No change
ON → ON	No change

The value of this field SHALL match the Mode field of one of the entries in the SupportedModes attribute.

1.10.6.4.1. OnMode with Power Up

If the On/Off feature is supported and the On/Off cluster attribute [StartUpOnOff](#) is present, with a value of On (turn on at power up), then the CurrentMode attribute SHALL be set to the OnMode attribute value when the server is supplied with power, except if the OnMode attribute is null.

1.10.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	ChangeTo-Mode	client ⇒ server	ChangeToModeResponse	O	M
0x01	ChangeTo-ModeResponse	client ⇐ server	N		M

1.10.7.1. ChangeToMode Command

This command is used to change device modes.

On receipt of this command the device SHALL respond with a ChangeToModeResponse command.

This command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NewMode	uint8	desc			M

1.10.7.1.1. NewMode Field

If the NewMode field doesn't match the Mode field of any entry of the SupportedModes list, the ChangeToModeResponse command's Status field SHALL indicate UnsupportedMode and the Status-Text field SHALL be included and MAY be used to indicate the issue, with a human readable string, or include an empty string.

If the NewMode field matches the Mode field of one entry of the SupportedModes list, but the device is not able to transition as requested, the ChangeToModeResponse command SHALL:

- Have the Status set to a product-specific Status value representing the error, or GenericFailure if