

1.10.7.2.1.2. Mode Base Status CommonCodes Range

The following table defines the common StatusCode values.

Status Code	Name	Summary
0x00	Success	Switching to the mode indicated by the NewMode field is allowed and possible. The CurrentMode attribute is set to the value of the NewMode field.
0x01	UnsupportedMode	The value of the NewMode field doesn't match any entries in the SupportedModes attribute.
0x02	GenericFailure	Generic failure code, indicating that switching to the mode indicated by the NewMode field is not allowed or not possible.
0x03	InvalidInMode	The received request cannot be handled due to the current mode of the device

The derived cluster code definitions SHALL NOT duplicate the common code definitions. For example, a derived cluster specification SHALL NOT define a status code with the same semantic as the common code of 0x01 (UnsupportedMode).

If the Status field is set to Success, the StatusText field is optional.

If the Status field is set to UnsupportedMode, the StatusText field SHALL be an empty string.

If the Status field is not set to Success or UnsupportedMode, the StatusText field SHALL include a vendor-defined error description which can be used to explain the error to the user. For example, if the Status field is set to InvalidInMode, the StatusText field SHOULD indicate why the transition to the requested mode is not allowed, given the current mode of the device, which may involve other clusters.

1.10.8. Mode Namespace

This section provides the definitions of the mode tag ranges and of the common standard mode tag values available in the instances of this cluster.

The following table defines the enumeration ranges for the ModeTagStruct Value field values.

Mode Tag Value Range	Range Name	Summary
0x0000 to 0x3FFF	CommonTags	Common standard values defined in this cluster specification.