

The derived cluster-specific error definitions SHALL NOT duplicate the general error definitions. That is, a derived cluster specification of this cluster cannot define errors with the same semantics as the general errors defined below.

The manufacturer-specific error definitions SHALL NOT duplicate the general error definitions or derived cluster-specific error definitions. That is, a manufacturer-defined error defined for this cluster or a derived cluster thereof cannot define errors with the same semantics as the general errors defined below or errors defined in a derived cluster. Such manufacturer-specific error definitions SHALL be scoped in the context of the Vendor ID present in the Basic Information cluster.

The set of ErrorStateID field values defined in each of the generic or derived Operational State cluster specifications is called ErrorState.

1.14.4.3.1. ErrorStateEnum GeneralErrors Range

The following table defines the generally applicable ErrorState values.

Value	Name	Summary	Conformance
0x00	NoError	The device is not in an error state	M
0x01	UnableToStartOrResume	The device is unable to start or resume operation	M
0x02	UnableToCompleteOperation	The device was unable to complete the current operation	M
0x03	CommandInvalidInState	The device cannot process the command in its current state	M

1.14.4.4. ErrorStateStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ErrorStateID	ErrorStateEnum	all		0	M
1	ErrorStateLabel	string	max 64		empty	ErrorStateID >= 0x80 & ErrorStateID <= 0xBF
2	ErrorStateDetails	string	max 64		empty	O

1.14.4.4.1. ErrorStateID Field

This SHALL be populated with a value from the [ErrorStateEnum](#).