

1.14.4.4.2. ErrorStateLabel Field

This field is present when the ErrorStateID is from the set reserved for Manufacturer Specific errors. If present, this SHALL contain a human-readable description of the error state.

1.14.4.4.3. ErrorStateDetails Field

This SHALL be a human-readable string that provides details about the error condition. As an example, if the ErrorStateID indicates that the device is a Robotic Vacuum that is stuck, the ErrorStateDetails contains "left wheel blocked".

1.14.5. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	PhaseList	list[string]	max 32[max 64]	X	MS	R V	M
0x0001	Current-Phase	uint8	desc	X	MS	R V	M
0x0002	Count-downTime	elapsed-s	max 259200	Q X	null	R V	O
0x0003	Operational-StateList	list[OperationalStateStruct]	desc		MS	R V	M
0x0004	Operational-State	OperationalStateEnum	all			R V	M
0x0005	OperationalError	ErrorStateStruct	desc			R V	M

1.14.5.1. PhaseList Attribute

This attribute SHALL indicate a list of names of different phases that the device can go through for the selected function or mode. The list may not be in sequence order. For example in a washing machine this could include items such as "pre-soak", "rinse", and "spin". These phases are manufacturer specific and may change when a different function or mode is selected.

A null value indicates that the device does not present phases during its operation. When this attribute's value is null, the CurrentPhase attribute SHALL also be set to null.

1.14.5.2. CurrentPhase Attribute

This attribute represents the current phase of operation being performed by the server. This SHALL be the positional index representing the value from the set provided in the PhaseList Attribute, where the first item in that list is an index of 0. Thus, this attribute SHALL have a maximum value that is "length(PhaseList) - 1".