

attribute list, the server SHALL stop operating.

1.17.7.4. SkipAreaResponse Command

This command is sent by the device on receipt of the SkipArea command.

This command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	SkipAreaStatus	all			M
1	StatusText	string	max 256			M

1.17.7.4.1. Status Field

If the Status field is set to Success or InvalidAreaList, the server MAY use a non-empty string for the StatusText field to provide additional information. For example, if Status is set to InvalidAreaList, the server MAY use StatusText to indicate why this list is invalid.

If the Status field is not set to Success or InvalidAreaList, the StatusText field SHALL include a vendor defined error description which can be used to explain the error to the user. For example, if the Status field is set to InvalidInMode, the StatusText field SHOULD indicate why the request is not allowed, given the current mode of the device, which MAY involve other clusters.