

2.11.5.6.1. Normal Value

This value SHALL indicate that the smoke sensor has nominal contamination levels, no customer action is required.

2.11.5.6.2. Low Value

This value SHALL indicate that the smoke sensor has detectable contamination levels, but the contamination is too low to cause a visible or audible alarm.

2.11.5.6.3. Warning Value

This value SHALL indicate that the smoke sensor has contamination levels in a warning state. At this level, the contamination may cause a visible or audible alarm. User intervention is suggested.

2.11.5.6.4. Critical Value

This value SHALL indicate that the smoke sensor has contamination levels in a critical state. At this level, the contamination should cause a visible or audible alarm. User intervention is required. Critical contamination of the sensor SHALL also be reflected as a HardwareFault.

2.11.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Expressed State	Expressed-StateEnum	all	N		R V	M
0x0001	Smoke-State	AlarmStateEnum	all	N		R V	SMOKE
0x0002	COState	AlarmStateEnum	all	N		R V	CO
0x0003	BatteryAlert	AlarmStateEnum	all	N		R V	M
0x0004	Device-Muted	MuteStateEnum	all	N		R V	O
0x0005	TestIn-Progress	bool	all			R V	M
0x0006	Hardware-FaultAlert	bool	all	N		R V	M
0x0007	EndOfServiceAlert	EndOfServiceEnum	all	N		R V	M
0x0008	InterconnectSmokeAlarm	AlarmStateEnum	all			R V	O