

2.11.7. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	SelfTestRequest	client ⇒ server	Y	O	O

2.11.7.1. SelfTestRequest Command

This command SHALL initiate a device self-test. The return status SHALL indicate whether the test was successfully initiated. Only one SelfTestRequest may be processed at a time. When the value of the ExpressedState attribute is any of SmokeAlarm, COAlarm, Testing, InterconnectSmoke, InterconnectCO, the device SHALL NOT execute the self-test, and SHALL return status code BUSY.

Upon successful acceptance of SelfTestRequest, the TestInProgress attribute SHALL be set to True and ExpressedState attribute SHALL be set to Testing. Any faults identified during the test SHALL be reflected in the appropriate attributes and events. Upon completion of the self test procedure, the SelfTestComplete event SHALL be generated, the TestInProgress attribute SHALL be set to False and ExpressedState attribute SHALL be updated to reflect the current state of the server.

2.11.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	SmokeAlarm	CRITICAL		V	SMOKE
0x01	COAlarm	CRITICAL		V	CO
0x02	LowBattery	INFO		V	M
0x03	Hardware-Fault	INFO		V	M
0x04	EndOfService	INFO		V	M
0x05	SelfTestComplete	INFO		V	M
0x06	AlarmMuted	INFO		V	O
0x07	MuteEnded	INFO		V	O
0x08	InterconnectSmokeAlarm	CRITICAL		V	[SMOKE]
0x09	InterconnectCOAlarm	CRITICAL		V	[CO]
0x0A	AllClear	INFO		V	M

2.11.8.1. SmokeAlarm Event

This event SHALL be generated when SmokeState attribute changes to either Warning or Critical state.