

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Alarm-SeverityLevel	AlarmStateEnum	all			M

2.11.8.1.1. AlarmSeverityLevel Field

This field SHALL indicate the current value of the SmokeState attribute.

2.11.8.2. COAlarm Event

This event SHALL be generated when COState attribute changes to either Warning or Critical state.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Alarm-SeverityLevel	AlarmStateEnum	all			M

2.11.8.2.1. AlarmSeverityLevel Field

This field SHALL indicate the current value of the COState attribute.

2.11.8.3. LowBattery Event

This event SHALL be generated when BatteryAlert attribute changes to either Warning or Critical state.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Alarm-SeverityLevel	AlarmStateEnum	all			M

2.11.8.3.1. AlarmSeverityLevel Field

This field SHALL indicate the current value of the BatteryAlert attribute.

2.11.8.4. HardwareFault Event

This event SHALL be generated when the device detects a hardware fault that leads to setting HardwareFaultAlert to True.