

The server SHALL NOT mark this attribute ready for report if the last time this was done was more recently than 1 second ago.

The server MAY delay marking this attribute ready for report for longer periods if needed, however the server SHALL NOT delay marking this attribute as ready for report for longer than 60 seconds.

If the voltage cannot be measured, a value of null SHALL be returned.

2.13.6.6. ActiveCurrent Attribute

This SHALL indicate the most recent [ActiveCurrent](#) reading in milliamps (mA).

A positive value represents current flowing into the server, while a negative value represents current flowing out of the server.

The reporting interval of this attribute SHALL be manufacturer dependent. The server MAY choose to omit publication of deltas considered not meaningful.

The server SHALL NOT mark this attribute ready for report if the last time this was done was more recently than 1 second ago.

The server MAY delay marking this attribute ready for report for longer periods if needed, however the server SHALL NOT delay marking this attribute as ready for report for longer than 60 seconds.

If the current cannot be measured, a value of null SHALL be returned.

2.13.6.7. ReactiveCurrent Attribute

This SHALL indicate the most recent [ReactiveCurrent](#) reading in milliamps (mA).

A positive value represents current flowing into the server, while a negative value represents current flowing out of the server.

The reporting interval of this attribute SHALL be manufacturer dependent. The server MAY choose to omit publication of deltas considered not meaningful.

The server SHALL NOT mark this attribute ready for report if the last time this was done was more recently than 1 second ago.

The server MAY delay marking this attribute ready for report for longer periods if needed, however the server SHALL NOT delay marking this attribute as ready for report for longer than 60 seconds.

If the current cannot be measured, a value of null SHALL be returned.

2.13.6.8. ApparentCurrent Attribute

This SHALL indicate the most recent [ApparentCurrent](#) (square root sum of the squares of active and reactive currents) reading in milliamps (mA).

A positive value represents current flowing into the server, while a negative value represents current flowing out of the server.