

2.14.5.3.1. Mfg Value

This value indicates the Zone is built-in and provided by the manufacturer of the device. Zones of this type can't be created or modified using commands in this cluster.

2.14.5.3.2. User Value

This value indicates the Zone was defined and created by a user. Zones of this type can be created, modified or deleted using commands in this cluster.

2.14.5.4. ZoneEventTriggeredReasonEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Motion	Zone event triggered because motion is detected	M

2.14.5.5. ZoneEventStoppedReasonEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	ActionStopped	Indicates that whatever triggered the Zone event has stopped being detected.	M
1	Timeout	Indicates that the max duration for detecting triggering activity has been reached.	M

2.14.5.6. TwoDCartesianVertexStruct Type

This struct is used to encode a point on the 2 Dimensional Cartesian Plane for the [TwoDCartesian-Zone](#) feature.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	X	uint16	all				M
1	Y	uint16	all				M

2.14.5.6.1. X Field

This field SHALL represent the position of the vertex along the horizontal (x) axis.