

| ID     | Name                      | Type                                        | Constraint          | Quality | Fallback | Access | Conformance   |
|--------|---------------------------|---------------------------------------------|---------------------|---------|----------|--------|---------------|
| 0x0004 | <b>SensitivityMax</b>     | uint8                                       | 2 to 10             | F       |          | R V    | M             |
| 0x0005 | <b>Sensitivity</b>        | uint8                                       | 1 to SensitivityMax | N       |          | RW VO  | !PERZONE-SENS |
| 0x0006 | <b>TwoD-Cartesian-Max</b> | <a href="#">TwoD-Cartesian-VertexStruct</a> |                     | F       |          | R V    | TWOD-CART     |

#### 2.14.6.1. MaxUserDefinedZones Attribute

This attribute SHALL specify the maximum number of user-defined zones that can be supported by the Node. This value is manufacturer-defined.

#### 2.14.6.2. MaxZones Attribute

This attribute SHALL specify the maximum number of zones allowed to created. This value SHALL be the sum of the number of predefined [Mfg Zones](#), and [MaxUserDefinedZones](#), if supported. This value is manufacturer-defined.

#### 2.14.6.3. Zones Attribute

This attribute SHALL specify all currently defined zones as a list of [ZoneInformationStruct](#). Use the commands from this cluster to add, update or remove entries.

#### 2.14.6.4. Triggers Attribute

This attribute SHALL specify all currently defined triggers controlling the generation of [ZoneTriggered](#) and [ZoneStopped](#) events and SHALL be a list of [ZoneTriggerControlStruct](#). To add an entry use [CreateOrUpdateTrigger](#). To remove an entry use [RemoveTrigger](#).

#### 2.14.6.5. SensitivityMax Attribute

This attribute SHALL specify the hardware specific value for the number of supported sensitivity levels. This value is manufacturer defined. If the PerZoneSensitivity feature is supported, the value of this attribute determines valid values for the Sensitivity field in [ZoneTriggerControlStruct](#); if the PerZoneSensitivity feature is not supported, the value of this attribute determines valid values for the [Sensitivity Attribute](#). Implementations require two to ten levels of sensitivity control in order to ensure that there is some user-level customization of the Trigger.

#### 2.14.6.6. Sensitivity Attribute

This attribute SHALL specify the sensitivity of the underlying zone triggering detection mechanism if the PerZoneSensitivity features is not supported. The higher the value the more sensitive the detection. The actual meaning of the values is implementation specific.