

Value	Name	Summary	Conformance
0	Deactivate	De-activate the color loop.	M
1	ActivateFromColorLoopStartEnhancedHue	Activate the color loop from the value in the ColorLoopStartEnhancedHue field.	M
2	ActivateFromEnhancedCurrentHue	Activate the color loop from the value of the EnhancedCurrentHue attribute.	M

3.2.6.11. ColorLoopDirectionEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Decrement	Decrement the hue in the color loop.	M
1	Increment	Increment the hue in the color loop.	M

3.2.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	CurrentHue	uint8	max 254	N P Q		R V	HS
0x0001	CurrentSaturation	uint8	max 254	N P Q S		R V	HS
0x0002	RemainingTime	uint16	max 65534	Q	0	R V	O
0x0003	CurrentX	uint16	max 65279	N P Q S		R V	XY
0x0004	CurrentY	uint16	max 65279	N P Q S		R V	XY
0x0005	DriftCompensation	DriftCompensationEnum	all		-	R V	O
0x0006	CompensationText	string	max 254		-	R V	O