

### 4.2.6.3. ControlModeEnum Type

This data type is derived from enum8.

| Value | Name                        | Summary                                                                                                                                   | Conformance |
|-------|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| 0     | <b>ConstantSpeed</b>        | The pump is running at a constant speed.                                                                                                  | SPD         |
| 1     | <b>ConstantPressure</b>     | The pump will regulate its speed to maintain a constant differential pressure over its flanges.                                           | PRSCONST    |
| 2     | <b>ProportionalPressure</b> | The pump will regulate its speed to maintain a constant differential pressure over its flanges.                                           | PRSCOMP     |
| 3     | <b>ConstantFlow</b>         | The pump will regulate its speed to maintain a constant flow through the pump.                                                            | FLW         |
| 5     | <b>ConstantTemperature</b>  | The pump will regulate its speed to maintain a constant temperature.                                                                      | TEMP        |
| 7     | <b>Automatic</b>            | The operation of the pump is automatically optimized to provide the most suitable performance with respect to comfort and energy savings. | AUTO        |

#### 4.2.6.3.1. ConstantSpeed Value

The setpoint is interpreted as a percentage of the range derived from the [MinConstSpeed – MaxConstSpeed] attributes.

#### 4.2.6.3.2. ConstantPressure Value

The setpoint is interpreted as a percentage of the range of the sensor used for this control mode. In case of the internal pressure sensor, this will be the range derived from the [MinConstPressure – MaxConstPressure] attributes. In case of a remote pressure sensor, this will be the range derived from the [MinMeasuredValue – MaxMeasuredValue] attributes of the remote pressure sensor.

#### 4.2.6.3.3. ProportionalPressure Value

The setpoint is interpreted as a percentage of the range derived of the [MinCompPressure – Max-