

CompPressure] attributes. The internal setpoint will be lowered (compensated) dependent on the flow in the pump (lower flow $\Rightarrow$ lower internal setpoint).

4.2.6.3.4. ConstantFlow Value

The setpoint is interpreted as a percentage of the range of the sensor used for this control mode. In case of the internal flow sensor, this will be the range derived from the [MinConstFlow – MaxConstFlow] attributes. In case of a remote flow sensor, this will be the range derived from the [MinMeasuredValue – MaxMeasuredValue] attributes of the remote flow sensor.

4.2.6.3.5. ConstantTemperature Value

The setpoint is interpreted as a percentage of the range of the sensor used for this control mode. In case of the internal temperature sensor, this will be the range derived from the [MinConstTemp – MaxConstTemp] attributes. In case of a remote temperature sensor, this will be the range derived from the [MinMeasuredValue – MaxMeasuredValue] attributes of the remote temperature sensor.

4.2.6.3.6. Automatic Value

This behavior is manufacturer defined. The pump can be stopped by setting the setpoint of the level control cluster to 0, or by using the On/Off cluster. If the pump is started (at any setpoint), the speed of the pump is entirely determined by the pump.

4.2.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	MaxPressure	int16	all	F X	null	R V	M
0x0001	MaxSpeed	uint16	all	F X	null	R V	M
0x0002	MaxFlow	uint16	all	F X	null	R V	M
0x0003	MinConstPressure	int16	all	F X	null	R V	PRSCONST, [AUTO]
0x0004	MaxConstPressure	int16	all	F X	null	R V	PRSCONST, [AUTO]
0x0005	MinCompPressure	int16	all	F X	null	R V	PRSCOMP, [AUTO]
0x0006	MaxCompPressure	int16	all	F X	null	R V	PRSCOMP, [AUTO]
0x0007	MinConstSpeed	uint16	all	F X	null	R V	SPD, [AUTO]
0x0008	MaxConstSpeed	uint16	all	F X	null	R V	SPD, [AUTO]
0x0009	MinConstFlow	uint16	all	F X	null	R V	FLW, [AUTO]