

4.3.7. Dependencies

For remote temperature sensing, the Temperature Measurement client cluster MAY be included on the same endpoint.

For occupancy sensing, the Occupancy Sensing client cluster MAY be included on the same endpoint.

4.3.8. Data Types

4.3.8.1. ALErrorCodeBitmap Type

This data type is derived from map32.

Bit	Name	Summary	Conformance
0	CompressorFail	Compressor Failure or Refrigerant Leakage	M
1	RoomSensorFail	Room Temperature Sensor Failure	M
2	OutdoorSensorFail	Outdoor Temperature Sensor Failure	M
3	CoilSensorFail	Indoor Coil Temperature Sensor Failure	M
4	FanFail	Fan Failure	M

4.3.8.2. HVACSystemTypeBitmap Type

This data type is derived from map8.

Bit	Name	Summary	Conformance
1..0	CoolingStage	Stage of cooling the HVAC system is using.	M
3..2	HeatingStage	Stage of heating the HVAC system is using.	M
4	HeatingIsHeatPump	Is the heating type Heat Pump.	M
5	HeatingUsesFuel	Does the HVAC system use fuel.	M

4.3.8.2.1. CoolingStage Bits

These bits SHALL indicate what stage of cooling the HVAC system is using.

- 00 = Cool Stage 1
- 01 = Cool Stage 2