

- 10 = Cool Stage 3
- 11 = Reserved

4.3.8.2.2. HeatingStage Bits

These bits SHALL indicate what stage of heating the HVAC system is using.

- 00 = Heat Stage 1
- 01 = Heat Stage 2
- 10 = Heat Stage 3
- 11 = Reserved

4.3.8.2.3. HeatingIsHeatPump Bit

This bit SHALL indicate whether the HVAC system is conventional or a heat pump.

- 0 = Conventional
- 1 = Heat Pump

4.3.8.2.4. HeatingUsesFuel Bit

This bit SHALL indicate whether the HVAC system uses fuel.

- 0 = Does not use fuel
- 1 = Uses fuel

4.3.8.3. OccupancyBitmap Type

This data type is derived from map8.

Bit	Name	Summary	Conformance
0	Occupied	Indicates the occupancy state	M

4.3.8.3.1. Occupied Bit

If this bit is set, it SHALL indicate the occupied state else if the bit is not set, it SHALL indicate the unoccupied state.

4.3.8.4. PresetTypeFeaturesBitmap Type

This data type is derived from map16.

Bit	Name	Summary	Conformance
0	Automatic	Preset may be automatically activated by the thermostat	M