

- The [PresetHandle](#) field is not provided
- The [PresetHandle](#) field on the encompassing [ScheduleStruct](#) is not provided
- The [SystemMode](#) field is provided and has the value Heat or Auto, or the [SystemMode](#) field on the parent [ScheduleStruct](#) has the value Heat or Auto

The [ScheduleTransitionStruct](#) SHALL be invalid if all the following are true:

- The [CoolingSetpoint](#) field is not provided
- The [PresetHandle](#) field is not provided
- The [PresetHandle](#) field on the encompassing [ScheduleStruct](#) is not provided
- The [SystemMode](#) field is provided and has the value Cool or Auto, or the [SystemMode](#) field on the parent [ScheduleStruct](#) has the value Cool or Auto

4.3.8.28.1. DayOfWeek Field

This field SHALL specify a bitmask of days of the week that the transition applies to. The Vacation bit SHALL NOT be set; vacation schedules SHALL be set via the vacation preset.

4.3.8.28.2. TransitionTime Field

This SHALL specify the time of day at which the transition becomes active, in terms of minutes within the day representing the wall clock, where 0 is 00:00:00, 1 is 00:01:00 and 1439 is 23:59:00.

Handling of transitions during the changeover of Daylight Saving Time is implementation-dependent.

4.3.8.28.3. PresetHandle Field

This field SHALL specify the preset used at the [TransitionTime](#). If this field is provided, then the [SystemMode](#), [CoolingSetpoint](#) and [HeatingSetpoint](#) fields SHALL NOT be provided.

4.3.8.28.4. SystemMode Field

This SHALL specify the default mode to which the thermostat will switch for this transition, overriding the default for the schedule. The only valid values for this field SHALL be Auto, Heat, Cool and Off. This field SHALL only be included when the required system mode differs from the schedule's default [SystemMode](#).

4.3.8.28.5. CoolingSetpoint Field

This field SHALL specify the cooling setpoint for the transition. If [PresetHandle](#) is set, this field SHALL NOT be included. Refer to [Setpoint Limits](#) for value constraints.

4.3.8.28.6. HeatingSetpoint Field

This field SHALL specify the heating setpoint for the transition. If [PresetHandle](#) is set, this field SHALL NOT be included. Refer to [Setpoint Limits](#) for value constraints.