

If the occupancy status of the room is unknown, this attribute SHALL NOT be used.

If a client changes the value of this attribute, the server supports the PRES and OCC features, and the Occupied bit is not set on the [Occupancy](#) attribute, the value of the [ActivePresetHandle](#) attribute SHALL be set to null.

4.3.9.16. UnoccupiedHeatingSetpoint Attribute

This attribute SHALL indicate the heating mode setpoint when the room is unoccupied.

Refer to [Setpoint Limits](#) for constraints.

If an attempt is made to set this attribute to a value greater than [MaxHeatSetpointLimit](#) or less than [MinHeatSetpointLimit](#), a response with the status code CONSTRAINT_ERROR SHALL be returned.

If this attribute is set to a value that is greater than ([UnoccupiedCoolingSetpoint](#) - [MinSetpointDeadBand](#)), the value of [UnoccupiedCoolingSetpoint](#) SHALL be adjusted to ([UnoccupiedHeatingSetpoint](#) + [MinSetpointDeadBand](#)).

If the occupancy status of the room is unknown, this attribute SHALL NOT be used.

If a client changes the value of this attribute, the server supports the PRES and OCC features, and the Occupied bit is not set on the [Occupancy](#) attribute, the value of the [ActivePresetHandle](#) attribute SHALL be set to null.

4.3.9.17. MinHeatSetpointLimit Attribute

This attribute SHALL indicate the minimum level that the heating setpoint MAY be set to.

This attribute, and the following three attributes, allow the user to define setpoint limits more constrictive than the manufacturer imposed ones. Limiting users (e.g., in a commercial building) to such setpoint limits can help conserve power.

Refer to [Setpoint Limits](#) for constraints. If an attempt is made to set this attribute to a value which conflicts with setpoint values then those setpoints SHALL be adjusted by the minimum amount to permit this attribute to be set to the desired value. If an attempt is made to set this attribute to a value which is not consistent with the constraints and cannot be resolved by modifying setpoints then a response with the status code CONSTRAINT_ERROR SHALL be returned.

4.3.9.18. MaxHeatSetpointLimit Attribute

This attribute SHALL indicate the maximum level that the heating setpoint MAY be set to.

Refer to [Setpoint Limits](#) for constraints. If an attempt is made to set this attribute to a value which conflicts with setpoint values then those setpoints SHALL be adjusted by the minimum amount to permit this attribute to be set to the desired value. If an attempt is made to set this attribute to a value which is not consistent with the constraints and cannot be resolved by modifying setpoints then a response with the status code CONSTRAINT_ERROR SHALL be returned.