

the [SetpointChangeSource](#) attribute; devices implementing [SetpointChangeAmount](#) SHOULD also implement [SetpointChangeSource](#).

The null value indicates that the previous setpoint was unknown.

4.3.9.35. SetpointChangeSourceTimestamp Attribute

This attribute SHALL indicate the time in UTC at which the [SetpointChangeAmount](#) attribute change was recorded.

4.3.9.36. OccupiedSetback Attribute

This attribute SHALL indicate the amount that the Thermostat server will allow the [Calculated Local Temperature](#) to float above the [OccupiedCoolingSetpoint](#) (i.e., [OccupiedCoolingSetpoint](#) + [OccupiedSetback](#)) or below the [OccupiedHeatingSetpoint](#) setpoint (i.e., [OccupiedHeatingSetpoint](#) – [OccupiedSetback](#)) before initiating a state change to bring the temperature back to the user's desired setpoint. This attribute is sometimes also referred to as the "span."

The purpose of this attribute is to allow remote configuration of the span between the desired setpoint and the measured temperature to help prevent over-cycling and reduce energy bills, though this may result in lower comfort on the part of some users.

The null value indicates the attribute is unused.

If the Thermostat client attempts to write [OccupiedSetback](#) to a value greater than [OccupiedSetbackMax](#), the Thermostat server SHALL set its [OccupiedSetback](#) value to [OccupiedSetbackMax](#) and SHALL send a Write Attribute Response command with a Status Code field enumeration of SUCCESS response.

If the Thermostat client attempts to write [OccupiedSetback](#) to a value less than [OccupiedSetbackMin](#), the Thermostat server SHALL set its [OccupiedSetback](#) value to [OccupiedSetbackMin](#) and SHALL send a Write Attribute Response command with a Status Code field enumeration of SUCCESS response.

4.3.9.37. OccupiedSetbackMin Attribute

This attribute SHALL indicate the minimum value that the Thermostat server will allow the [OccupiedSetback](#) attribute to be configured by a user.

The null value indicates the attribute is unused.

4.3.9.38. OccupiedSetbackMax Attribute

This attribute SHALL indicate the maximum value that the Thermostat server will allow the [OccupiedSetback](#) attribute to be configured by a user.

The null value indicates the attribute is unused.

4.3.9.39. UnoccupiedSetback Attribute

This attribute SHALL indicate the amount that the Thermostat server will allow the [Calculated](#)