

ID	Name	Direction	Response	Access	Conformance
0x05	SetActiveScheduleRequest	client ⇒ server	Y	O	MSCH
0x06	SetActivePre-setRequest	client ⇒ server	Y	O	PRES

4.3.10.1. SetpointRaiseLower Command

This command will raise or lower the setpoint based on the provided values.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Mode	SetpointRaiseLowerModeEnum	desc			M
1	Amount	int8	all			M

4.3.10.1.1. Mode Field

The field SHALL specify which setpoints are to be adjusted.

4.3.10.1.1.1. Heat Value

If the server does not support the HEAT feature then it SHALL respond with INVALID_COMMAND. If the server supports the AUTO feature and the resulting setpoint would be invalid solely due to [MinSetpointDeadBand](#) then the Cooling setpoint SHALL be increased sufficiently to maintain the deadband.

4.3.10.1.1.2. Cool Value

If the server does not support the COOL feature then it SHALL respond with INVALID_COMMAND. If the server supports the AUTO feature and the resulting setpoint would be invalid solely due to [MinSetpointDeadBand](#) then the Heating setpoint SHALL be decreased sufficiently to maintain the deadband.

4.3.10.1.1.3. Both Value

The client MAY indicate Both regardless of the server feature support. The server SHALL only adjust the setpoint that it supports and not respond with an error.

4.3.10.1.2. Amount Field

This field SHALL indicate the amount (possibly negative) that should be added to the setpoint(s), in steps of 0.1°C.