

When this attribute is successfully written to, the [PercentSetting](#) and [SpeedSetting](#) (if present) attributes SHALL be set to appropriate values, as defined by [Section 4.4.6.3.1, “Percent Rules”](#) and [Section 4.4.6.6.1, “Speed Rules”](#) respectively, unless otherwise specified below.

When this attribute is set to any valid value, the [PercentCurrent](#) and [SpeedCurrent](#) (if present) attributes SHALL indicate the actual currently operating fan speed, unless otherwise specified below.

4.4.6.1.1. Off Value

Successfully setting the attribute value to Off SHALL set the values of these attributes to 0 (zero):

- [PercentSetting](#)
- [PercentCurrent](#)
- [SpeedSetting](#) (if present)
- [SpeedCurrent](#) (if present)

4.4.6.1.2. Auto Value

Successfully setting the attribute value to Auto SHALL set the values of these attributes to null:

- [PercentSetting](#)
- [SpeedSetting](#) (if present)

These attributes SHALL continue to indicate the current state of the fan while this attribute value is Auto:

- [PercentCurrent](#)
- [SpeedCurrent](#) (if present)

4.4.6.1.3. On Value

If a client attempts to write a value of On, the attribute SHALL be set to High.

4.4.6.1.4. Smart Value

If a client attempts to write a value of Smart, this attribute SHALL be set to Auto if the AUT feature is supported, otherwise the attribute SHALL be set to High.

4.4.6.2. FanModeSequence Attribute

This attribute indicates the fan speed ranges that SHALL be supported by the server.

4.4.6.3. PercentSetting Attribute

This attribute SHALL indicate the speed setting for the fan with a value of 0 indicating that the fan is off and a value of 100 indicating that the fan is set to run at its maximum speed. If the [FanMode](#) attribute is set to Auto, the value of this attribute SHALL be set to null.

This attribute MAY be written to by a client to indicate a new fan speed. If a client writes null to this