

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M

5.2.10.5.1. UserID Field

This field SHALL indicate the user ID. The value of the UserID field SHALL be between 0 and the value of the NumberOfPINUsersSupported attribute.

5.2.10.6. GetPINCodeResponse Command

Returns the PIN for the specified user ID.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M
1	UserStatus	UserStatusEnum	desc	X		M
2	UserType	UserTypeEnum	desc	X		M
3	PINCode	octstr		X		M

If the requested UserID is valid and the Code doesn't exist, Get RFID Code Response SHALL have the following format:

UserID = requested User ID

UserStatus = 0 (Available)

UserType = Null (Not supported)

PINCode = 0 (zero length)

If the requested UserID is invalid, send Default Response with an error status. The error status SHALL be equal to CONSTRAINT_ERROR when User_ID is less than the max number of users supported, and NOT_FOUND if greater than or equal to the max number of users supported.

5.2.10.7. ClearPINCode Command

Clear a PIN code or all PIN codes.