

Name	Summary
INVALID_COMMAND	One or more fields violates constraints or is invalid. Door lock is unable to switch from restricted to unrestricted user (e.g. need to clear schedules to switch).

5.2.10.24.1. UserID Field

This field SHALL indicate the user ID.

5.2.10.24.2. UserType Field

This field SHALL indicate the user type.

5.2.10.25. GetUserType Command

Retrieve the user type for a specific user.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M

5.2.10.26. GetUserTypeResponse Command

Returns the user type for the specified user ID. If the requested User ID is invalid, send Default Response with an error status equal to FAILURE.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M
1	UserType	UserType-Enum	all			M

5.2.10.27. SetRFIDCode Command

Set an ID for RFID access into the lock.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M
1	UserStatus	UserStatusEnum	desc	X		M
2	UserType	UserType-Enum	desc	X		M
3	RFIDCode	octstr				M