

Return status is a global status code or a cluster-specific status code from the [Status Codes](#) table and SHALL be one of the following values:

Name	Summary
SUCCESS	Setting RFID code was successful.
FAILURE	Setting RFID code failed.
CONSTRAINT_ERROR	Setting RFID code failed because User ID requested was out of range.
DUPLICATE	Setting RFID code failed because it would create a duplicate RFID code.

5.2.10.27.1. UserID Field

This field SHALL indicate the user ID.

The value of the UserID field SHALL be between 0 and the value of the NumberOfRFIDUsersSupported attribute.

5.2.10.27.2. UserStatus Field

This field SHALL indicate what the status is for a specific user ID. The values are according to “Set PIN” while not all are supported.

Only the values 1 (Occupied/Enabled) and 3 (Occupied/Disabled) are allowed for UserStatus.

5.2.10.27.3. UserType Field

The values are the same as used for SetPINCode command.

5.2.10.28. GetRFIDCode Command

Retrieve an RFID code.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserID	uint16	desc			M

5.2.10.28.1. UserID Field

This field SHALL indicate the user ID.

The value of the UserID field SHALL be between 0 and the value of the NumberOfRFIDUsersSupported attribute.

5.2.10.29. GetRFIDCodeResponse Command

Returns the RFID code for the specified user ID.