

SHALL be one of the following values:

- SUCCESS, if setting User was successful.
- FAILURE, if some unexpected internal error occurred setting User.
- OCCUPIED, if OperationType is Add and UserIndex points to an occupied slot.
- INVALID_COMMAND, if one or more fields violate constraints or are invalid or if OperationType is Modify and UserIndex points to an available slot.

5.2.10.32.1. OperationType Field

This field SHALL indicate the type of operation.

5.2.10.32.2. UserIndex Field

This field SHALL indicate the user ID.

5.2.10.32.3. UserName Field

This field SHALL contain a string to use as a human readable identifier for the user.

If UserName is null then:

- If the OperationType is Add, the UserName in the resulting user record SHALL be set to an empty string.
- If the OperationType is Modify, the UserName in the user record SHALL NOT be changed from the current value.

If UserName is not null, the UserName in the user record SHALL be set to the provided value.

5.2.10.32.4. UserUniqueID Field

This field SHALL indicate the fabric assigned number to use for connecting this user to other users on other devices from the fabric's perspective.

If UserUniqueID is null then:

- If the OperationType is Add, the UserUniqueID in the resulting user record SHALL be set to default value specified above.
- If the OperationType is Modify, the UserUniqueID in the user record SHALL NOT be changed from the current value.

If UserUniqueID is not null, the UserUniqueID in the user record SHALL be set to the provided value.

5.2.10.32.5. UserStatus Field

This field SHALL indicate the UserStatus to assign to this user when created or modified.

If UserStatus is null then: